



ControlNet Modular Repeater Adapter

Cat. no. 1786-RPA/B

What's in this Document?

Use this document to install a 1786-RPA/B ControlNet repeater adapter. The 1786-RPA/B is a direct replacement for the 1786-RPA/A repeater adapter. No software or network modifications are necessary to replace a 1786-RPA/A with a 1786-RPA/B.

For information on this topic:	See page:
Important User Information	1
About the ControlNet Repeater Adapter	4
Mounting the Repeater Adapter	5
Wiring the Repeater Adapter	9
Status Indicator LEDs	11
Mounting Dimensions	14
Specifications	15
Operating in Hazardous Environments	17

Important User Information

Because of the variety of uses for the products described in this publication, those responsible for the application and use of these products must satisfy themselves that all necessary steps have been taken to assure that each application and use meets all performance and safety requirements, including any applicable laws, regulations, codes and standards. In no event will Rockwell Automation be responsible or liable for indirect or consequential damage resulting from the use or application of these products.

Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for purposes of example. Since there are many variables and requirements associated with any particular installation, Rockwell Automation does not assume responsibility or liability (to include intellectual property liability) for actual use based upon the examples shown in this publication.

Allen-Bradley publication SGI-1.1, *Safety Guidelines for the Application, Installation and Maintenance of Solid-State Control* (available from your local Rockwell Automation office), describes some important differences between solid-state equipment and electromechanical devices that should be taken into consideration when applying products such as those described in this publication.

Reproduction of the contents of this copyrighted publication, in whole or part, without written permission of Rockwell Automation, is prohibited.

Throughout this publication, notes may be used to make you aware of safety considerations. The following annotations and their accompanying statements help you to identify a potential hazard, avoid a potential hazard, and recognize the consequences of a potential hazard:

WARNING



Identifies information about practices or circumstances that can cause an explosion in a hazardous environment, which may lead to personal injury or death, property damage, or economic loss.

ATTENTION



Identifies information about practices or circumstances that can lead to personal injury or death, property damage, or economic loss.

IMPORTANT

Identifies information that is critical for successful application and understanding of the product.

ATTENTION**Environment and Enclosure**

This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC publication 60664-1), at altitudes up to 2000 meters without derating.

This equipment is considered Group 1, Class A industrial equipment according to IEC/CISPR Publication 11. Without appropriate precautions, there may be potential difficulties ensuring electromagnetic compatibility in other environments due to conducted as well as radiated disturbance.

This equipment is supplied as “open type” equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

See NEMA Standards publication 250 and IEC publication 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure. Also, see the appropriate sections in this publication, as well as the Allen-Bradley publication 1770-4.1 (“Industrial Automation Wiring and Grounding Guidelines”), for additional installation requirements pertaining to this equipment.

ATTENTION



Preventing Electrostatic Discharge

This equipment is sensitive to electrostatic discharge, which can cause internal damage and affect normal operation. Follow these guidelines when you handle this equipment:

- Touch a grounded object to discharge potential static.
 - Wear an approved grounding wrist strap.
 - Do not touch connectors or pins on component boards.
 - Do not touch circuit components inside the equipment.
 - If available, use a static-safe workstation.
 - When not in use, store the equipment in appropriate static-safe packaging.
-

About the ControlNet Repeater Adapter

Use a repeater adapter (1786-RPA/B) with repeater modules (1786-RPCD, -RPF5, -RPFM, -RPFRL and -RPFRXL) to build a ControlNet repeater. A repeater can be used to extend the length of the network, create a star or point topology, or perform network media conversion from copper to fiber, and vice versa.


The repeater adapter provides:

- digital re-timing of ControlNet data
- power to repeater modules
- one coax channel
- LED indicators

The repeater adapter ships with the following items:

- 1 removable terminal block (power connector) attached to the repeater adapter
- 1 75-ohm terminator for terminating an unused port
- 2 DIN rail locks
- this manual (publication 1786-IN013, ControlNet Modular Repeater Adapter Installation Instructions)

See Figure 1 on page 5 for repeater adapter components.

Figure 1 Repeater adapter components

Mounting the Repeater Adapter

To mount the repeater adapter on the DIN rail:


ATTENTION



This product is grounded through the DIN rail to chassis ground. Use zinc plated yellow-chromate steel DIN rail to assure proper grounding. The use of other DIN rail materials (e.g. aluminum, plastic, etc.) that can corrode, oxidize, or are poor conductors, can result in improper or intermittent grounding.


1. Position the repeater adapter on the 35 x 7.5mm DIN rail (A-B part number 199-DR1) at a 30° angle.

Figure 2 Mount the repeater adapter on the DIN rail




2. Hook the lip on the rear of the repeater adapter onto the top of the DIN rail, and rotate the repeater adapter onto the rail.

Figure 3 Install the repeater adapter on the DIN rail




3. Press the repeater adapter down onto the DIN rail until flush. The locking tab should snap into position and lock the repeater adapter to the DIN rail.
4. If the repeater adapter does not snap into position, use a screwdriver or similar device to move the locking tab down while pressing the repeater adapter flush onto the DIN rail. Release the locking tab to lock the adapter in place. If necessary, push up on the locking tab to lock.

Figure 4 Lock the repeater adapter in place on the DIN rail

5. Once the repeater adapter is attached to the DIN rail, slide the repeater modules to the left to mate with the repeater adapter.

IMPORTANT

The total power consumption of all attached repeater modules cannot exceed 8W or 1.6A @ 5V.

Figure 5 Mate the repeater adapters**IMPORTANT**


Make certain that the repeater adapter and modules are secured together with DIN rail locks (cat. no. 1492-EA35) on either side.

Failure to do so may result in the loss of communications and/or cause damage to the modules.


6. Attach the DIN rail locks to the left side of the repeater adapter and the right side of the attached modules to lock the repeater adapter and modules in place.
7. Repeat the following steps for each of the 2 DIN rail locks.
 - a. Position the DIN rail lock on the 35 x 7.5mm DIN rail at a 30° angle.
 - b. Hook the lip on the back of the DIN rail lock onto the top of the DIN rail and rotate the DIN rail lock onto the rail.
 - c. Press the DIN rail lock down onto the DIN rail. The DIN rail lock should snap into position.
 - d. Tighten the 2 screws on the DIN rail lock to a torque of 1.1 Nm (9-11 in-lbs).

Figure 6 Attach the DIN rail locks


Position the DIN rail lock to the DIN rail.



Tighten the 2 screws on the DIN rail lock to a torque of 1.1 Nm (9-11 in-lbs).



Press the DIN rail lock down onto the DIN rail.



8. Wire the repeater adapter. Refer to Wiring the Repeater Adapter on page 9.
9. Terminate any unused coax ports by connecting a 75-ohm terminator to the unused BNC connector(s). One 75-ohm terminator is shipped with the repeater adapter.

Wiring the Repeater Adapter

WARNING

When you connect or disconnect the removable terminal block (RTB) with field side power applied, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.

WARNING

If you connect or disconnect the ControlNet cable with power applied to this module or any device on the network, an electrical arc can occur. This could cause an explosion in hazardous location installations.

Be sure that power is removed or the area is nonhazardous before proceeding.

TIP**Before you begin**

Make sure you have obtained the following items before you begin to wire the module:


- two lengths of 12 - 24 AWG wire
- a wire stripping tool
- a small, flat head screwdriver

1. Strip about 7 mm of insulation from the end of each wire.
2. Attach the V_{in+} wire to one of the V_{in+} terminals on the RTB. Tighten down the screws to 0.6-0.8 Nm (5-7 in-lbs).
3. Attach the V_{in-} wire to one of the V_{in-} terminals on the RTB. Tighten down the screws to 0.6-0.8 Nm (5-7 in-lbs).

TIP


The unused V_{in+} and V_{in-} terminals can be used to supply power to other devices.

Figure 7 Attach the V_{in+} and V_{in-} wire



4. Install the RTB onto the repeater adapter. Tighten down the screws to 0.6-0.8 Nm (5-7 in-lbs).
5. Connect the repeater adapter to the ControlNet network by connecting the drop line of the coax tap to the BNC connector.


Figure 8 Connect the ControlNet dropline



6. Terminate any unused coax ports by connecting a 75-ohm terminator to the unused BNC connector(s). One 75-ohm terminator is shipped with the repeater adapter.

Status Indicator LEDs

Figure 9 Status indicator LEDs



31453-M

The status indicator LEDs on the repeater adapter can be interpreted singly or together. The following three tables list different combinations of LEDs and their interpretations.

These status indicator LEDs and their interpretations	... are shown in
repeater adapter and repeater modules	Table 1
repeater adapter only	Table 2
repeater modules only	Table 3

IMPORTANT

The following are the only valid indicator combinations. Other combinations are not valid. For example, the combination of the repeater adapter indicator being solid green and the repeater modules indicator being solid red is not valid and probably indicates a defective module.

Table 1 Repeater adapter and modules indicators

If both are:	This means:	So you should:
Alternating red/green	The repeater adapter is being powered up or reset.	Do nothing. The repeater adapter is operating properly.
Solid red	A jabber condition has occurred. Another node or repeater on the network is transmitting constantly.	Check the network and components for proper operation.
Off	The repeater adapter is not powered or has failed.	Check the power input to the repeater adapter for correct voltage and polarity.

Table 2 Repeater adapter indicator


If the Repeater Adapter indicator is:	This means:	So you should:
Solid Green	Error-free data is being recovered at the coax port of the repeater adapter.	Do nothing. This is the normal operating mode.
Flashing green/off	Data with errors is occasionally being recovered at the coax port of the repeater adapter.	This situation will normally correct itself. If the situation persists check that: <ul style="list-style-type: none"> • all BNC connector pins are seated properly • all taps are Rockwell Automation taps • all terminators are 75Ω and are installed at both ends of all segments • the coax cable has not been grounded
Flashing red/off	Either no data is being received at the coax port of the repeater adapter, or data with a large number of errors is being received at the coax port of the repeater adapter.	Check for: <ul style="list-style-type: none"> • broken cables • broken taps • missing segment terminators

Table 3 Repeater modules indicator

If the Repeater modules indicator is:	This means:	So you should:
Solid Green	Error-free data is being recovered at all of the attached repeater modules.	Do nothing. This is the normal operating mode.
Flashing green/off	Data with errors is occasionally being recovered at some or all of the repeater modules.	This situation will normally correct itself. If the situation persists check that: <ul style="list-style-type: none"> • all BNC connector pins are seated properly. • all taps are Rockwell Automation taps. • all terminators are 75Ω and are installed at both ends of all segments • the coax cable has not been grounded. • fiber optic connectors are of the correct type and are correctly attached to the fiber optic cable. • fiber optic cable is of the correct type.
Flashing red/off	Either no data is being received at the any repeater modules, or the received data at some or all of the repeater modules has a high number of errors.	Check for: <ul style="list-style-type: none"> • broken cables • broken taps • missing segment terminators

Mounting Dimensions

Figure 10 Repeater adapter mounting dimensions



31458-M

Specifications

Table 4 Specifications

Specification:	Range or description:
Power Supply	UL listed and/or CSA certified CLASS 2 power supply. You must use a Safety Extra Low Voltage (SELV) power supply to power this repeater adapter.
Input Voltage Rating	24V dc nominal
Input Voltage Range	18.0V to 36.0V dc
Repeater Backplane Output Current	1.6A maximum @5 V dc
Isolation Voltage	Qualification tested at 750V dc for 60 seconds between 24 V input and ControlNet
Power Consumption	700mA maximum from external 24V supply based on worst case module loading (16.8 W; 57.4 BTU/hr.)
Operating Temperature	IEC 60068-2-1 (Test Ad, Operating Cold), IEC 60068-2-2 (Test Bd, Operating Dry Heat), IEC 60068-2-14 (Test Nb, Operating Thermal Shock): 0 to 60°C (32 to 140°F)
Storage Temperature	IEC 60068-2-1 (Test Ab, Un-packaged Non-operating Cold), IEC 60068-2-2 (Test Bb, Un-packaged Non-operating Dry Heat) IEC 60068-2-14 (Test Na, Un-packaged Non-operating Thermal Shock): -40 to 85°C (-40 to 185°F)
Relative Humidity	IEC 60068-2-30 (Test Db, Unpackaged Non-operating Damp Heat): 5 to 95% condensing
Shock	IEC 60068-2-27 (Test Ea, Unpackaged shock): Operating 30g Non-operating 50g
Vibration	IEC 60068-2-6 (Test Fc, Operating): 5g @10-500Hz
Emissions	CISPR 11: Group 1, Class A
ESD Immunity	IEC 61000-4-2: 6kV contact discharges 8kV air discharges
Radiated RF Immunity	IEC 61000-4-3: 10V/m with 1kHz sine-wave 80%AM from 80MHz to 2000MHz 10V/m with 200Hz 50% Pulse 100%AM at 900MHz
EFT/B Immunity	IEC-61000-4-4: ±4kV @ 2.5kHz on power ports ±4kV @ 2.5kHz on communications ports

Table 4 Specifications

Specification:	Range or description:
Surge Transient Immunity	IEC 61000-4-5: ±1kV line-line (DM) and ±2kV line-earth (CM) on power ports ±2kV line-earth (CM) on shielded ports
Conducted RF Immunity	IEC 61000-4-6: 10Vrms with 1kHz sine-wave 80%AM from 150kHz to 80MHz
Enclosure Type Rating	None (open-style)
Power Conductors	12 AWG (3.31 sq. mm) maximum, 24 AWG (0.205 sq. mm) minimum Category 2 ¹
Certifications: (when product is marked)	UL Listed Industrial Control Equipment CSA Certified Process Control Equipment CSA Certified Process Control Equipment for Class I, Division 2 Group A,B,C,D Hazardous Locations FM Approved Equipment for use in Class I Division 2 Group A,B,C,D Hazardous Locations CE ² European Union 89/336/EEC EMC Directive, compliant with: EN 50082-2; Industrial Immunity EN 61326; Meas./Control/Lab., Industrial Requirements EN 61000-6-2; Industrial Immunity EN 61000-6-4; Industrial Emissions C-Tick ² Australian Radiocommunications Act, compliant with AS/NZS 2064; Industrial Emissions
Mounting Orientation	Any mounting orientation
Minimum Enclosure	12 in. L x 7.75 in. W x 4 in. D
Accessories	ControlNet taps (1786-TPR, -TPY, -TPS) 35 x 7.5mm DIN rail (Rockwell Automation part number 199-DR1)

¹ Wiring Category itemized for all I/O types (signal, power, communications, etc.) according to, Allen-Bradley publication 1770-4.1 ("Industrial Automation Wiring and Grounding Guidelines") or appropriate System Level Installation Manual.

² See the Product certification link at www.ab.com for Declarations of Conformity, Certificates, and other certification details.

Operating in Hazardous Environments

<p>The following information applies when operating this equipment in hazardous locations:</p>	<p>Informations sur l'utilisation de cet équipement en environnements dangereux:</p>		
<p>Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local Authority Having Jurisdiction at the time of installation.</p>	<p>Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.</p>		
<p style="text-align: center;">WARNING</p> 	<p style="text-align: center;">EXPLOSION HAZARD</p> <ul style="list-style-type: none"> • Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous. • Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product. • Substitution of components may impair suitability for Class I, Division 2. • If this product contains batteries, they must only be changed in an area known to be nonhazardous. 	<p style="text-align: center;">AVERTISSEMENT</p> 	<p style="text-align: center;">RISQUE D'EXPLOSION</p> <ul style="list-style-type: none"> • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement. • Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit. • La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2. • S'assurer que l'environnement est classé non dangereux avant de changer les piles.

Notes:

Notes:

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4800, Fax: (1) 864.281.2433

Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

Publication 1786-IN013B-EN-P - June 2002

PN 957400-86

Supersedes Publication 1786-5.13 - February 1998

Copyright © 2002 Rockwell Automation. All rights reserved. Printed in the U.S.A.