



# 1334-MOD-H

## Omit Local Operating Devices

**Description** The 1334-MOD-H Option Kit is designed for use in any Bulletin 1334 460 or 575V AC Drive. The kit provides a blank control panel which allows local operating devices to be removed from the Drive enclosure door.

**Each 1334-MOD-H Option Kit Includes:**

- (1) Blank Control Panel, P/N 171252-007

**IMPORTANT**

When removing the local **STOP** function, it is the user's responsibility to meet any industry, local or national codes regarding operator and machine safety. Alternate control devices are the user's responsibility. Refer to the 1334 instruction manual and the appropriate option sheets for connection requirements.

**Installation**





**WARNING**

Only personnel familiar with the Drive and its associated machinery should plan or implement the installation, startup, and adjustment of MOD kits. Failure to comply may result in personal injury and/or equipment damage.

To guard against personal injury, always remove & lock out power to the Drive at the main supply disconnect and all other power source disconnects. Ensure that DS1 is not lit when boards or wires are being installed or connected. Refer to the instruction manual for your Drive for LED location.

Installation involves removing input power to the Drive at the disconnect device, disconnecting leads at the main control terminal block and installing the blank control panel in the Drive. The existing control wire harness or ribbon cable may be left in the Drive once leads have been disconnected and trimmed back.



*With offices in major cities worldwide.*

**WORLD HEADQUARTERS**  
 1201 South Second Street  
 Milwaukee, WI 53204 USA  
 Tel: (414) 382-2000  
 Telex: 43 11 016  
 FAX: (414) 382-2400

**EUROPE/INDIA/MIDDLE EAST/  
 AFRICA HEADQUARTERS**  
 Allen-Bradley  
 International Limited  
 Chiltern House  
 45 Station Road  
 Henley-on-Thames  
 Oxon, RG9 1AT England  
 Tel: (44) 491-577013  
 Telex: 851 849782  
 FAX: (44) 491-578933

**ASIA/PACIFIC HEADQUARTERS**  
 Allen-Bradley(Hong Kong) Limited  
 2901 Great Eagle Center  
 23 Harbour Road  
 G.P.O. Box 9797  
 Wanchai, Hong Kong  
 Tel: (852) 5-739391  
 Telex: 780 64347  
 FAX: (852) 5-745326

**CANADA HEADQUARTERS**  
 Allen-Bradley Canada Limited  
 135 Dundas Street  
 Cambridge, Ontario N1R 5X1  
 Canada  
 Tel: (519) 623-1810  
 Telex: 069 59317  
 FAX: (519) 623-8930

**LATIN AMERICA  
 HEADQUARTERS**  
 1201 South Second Street  
 Milwaukee, WI 53204 USA  
 Tel: (414) 382-2000  
 Telex: 43 11 016  
 FAX: (414) 382-2400

**MOTION CONTROL DIVISION**  
 4300 West Brown Deer Road  
 Brown Deer, WI 53223