




# Packing Data

## 1747 Open Controller Parallel Adapter Cable (1747-OCP252)

### What's In This Package

The open controller parallel adapter cable connects an open controller CPU (1747-OCExxxA) to a parallel cable or device. Make sure that you have this cable before you discard any packing material.



Pin	Description	Pin	Description
1	strobe <sup>①</sup>	14	auto feed <sup>①</sup>
2	data bit 0	15	error <sup>①</sup>
3	data bit 1	16	initialize printer <sup>①</sup>
4	data bit 2	17	select input <sup>①</sup>
5	data bit 3	18	common
6	data bit 4	19	common
7	data bit 5	20	common
8	data bit 6	21	common
9	data bit 7	22	common
10	acknowledge <sup>①</sup>	23	common
11	busy	24	common
12	paper end	25	common
13	select		

<sup>①</sup> low true

20780-M

