



GuardPLC OPC Server

(Catalog Numbers 1753-OPC)

System Requirements

Before you install the GuardPLC OPC software, make sure your personal computer meets the following system requirements:


Category	Requirement
Personal Computer	Pentium®II, 350 MHz
Operating System	Windows NT/2000
RAM	128 MB
Free Hard Disk Space	at least 150 MB plus space for user programs
Ethernet Card(s)	up to 4, configured for TCP/IP

Installing GuardPLC OPC Software

You must have administrator access to the computer on which you are installing the OPC server.

1. Insert the GuardPLC OPC Server CD-ROM into the CD drive.

If Autoplay is enabled, the software installation starts automatically. If this is not the case, you can start the installation by clicking on d:\RSLogix_Guard_PLUS_OPCServer\setup.exe (where “d” is your CD drive).



2. On the setup screen, click on Install GuardPLC OPC Server and follow the installation prompts. You will be prompted to enter your serial number, which is found on your license agreement.

TIP

To uninstall the GuardPLC OPC server, use the Add/Remove Programs tool in your Windows® Control Panel.

www.rockwellautomation.com

Corporate Headquarters

Rockwell Automation, 777 East Wisconsin Avenue, Suite 1400, Milwaukee, WI, 53202-5302 USA, Tel: (1) 414.212.5200, Fax: (1) 414.212.5201

Headquarters for Allen-Bradley Products, Rockwell Software Products and Global Manufacturing Solutions

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe: Rockwell Automation SA/NV, Vorstlaan/Boulevard du Souverain 36-BP 3A/B, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Headquarters for Dodge and Reliance Electric Products

Americas: Rockwell Automation, 6040 Ponders Court, Greenville, SC 29615-4617 USA, Tel: (1) 864.297.4900, Fax: (1) 864.281.2433

Europe: Rockwell Automation, Brühlstraße 22, D-74834 Elztal-Dallau, Germany, Tel: (49) 6261 9410, Fax: (49) 6261 17741

Asia Pacific: Rockwell Automation, 55 Newton Road, #11-01/02 Revenue House, Singapore 307987, Tel: (65) 351 6723, Fax: (65) 355 1733

Publication 1753-IN007A-EN-P - March 2004

PN 40071-168-01(1)

Copyright © 2004 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.