



Read This First

ATTENTION

24V dc FLEX I/O RTD Input Module (Cat. No. 1794-IR8)



ATTENTION: This RTD input module differs from previous versions of the module as follows:

- when sensing an open sensor, the module will indicate a **full upscale** reading for that particular sensor (for example, if a 100 Ω RTD has a range of -200°C to $+870^{\circ}\text{C}$, an open sensor will result in a reading of 870°C).
- both the overrange **and** underrange bits are set (1) when the low wire of the sensor is open

Make certain you monitor the overrange and underrange bits when an RTD indicates an upscale reading.

 **Rockwell** Automation

Allen-Bradley

With major offices worldwide.

World Headquarters,
Allen-Bradley,
1201 South Second Street,
Milwaukee, WI 53204 USA,
Tel: (1) 414 382-2000 Fax: (1) 414 382-4444

Pub. 1794-5.22-RN1 – December 1997

PN955128-91

Copyright 1997 Allen-Bradley Company, Inc. Printed in USA

Allen-Bradley A