



Quick Reference

FLEX I/O Terminal Base Cross Reference

Use the following table to determine which terminal base unit will best meet your application needs.

✓ = Recommended Base • = Compatible Base(s)

1794-	TB2	TB3	TB3S	TB3T	TB3TS	TB3G	TB3GS	TBN	TBNF	1794-	TB2	TB3	TB3S	TB3T	TB3TS	TB3G	TB3GS	TBN	TBNF	
IA8	•	•	•					✓		IV16		✓	•							
IA8I	•	•	•					✓		OB8		✓	•						•	
IA16		•	•					✓		OB16		✓	•							
OA8	•	•	•					•	✓	OB16P		✓	•							
OA8I	•	•	•					•	✓	OV16	•	✓	•							
OA16		•	•					✓		OV16P	•	✓	•							
IM8								✓		OB8EP		✓	•						•	
OM8								✓		IB10XOB6		✓	•							
IB8	•	✓	•							IC16	•	✓	•							
IB16		✓	•							OC16	•	✓	•							

Allen-Bradley PLCs

✓ = Recommended Base • = Compatible Base(s)

1794-										1794-									
TB2	TB3	TB3S	TB3T	TB3TS	TB3G	TB3GS	TBN	TBNF		TB2	TB3	TB3S	TB3T	TB3TS	TB3G	TB3GS	TBN	TBNF	
•	✓	•	•	•						OW8	•	•	•					•	✓
•	✓	•	•	•			•			IR8		✓	•	•					
•	✓	•	•	•						IRT8					✓	•			
•	✓	•	•	•			•			IT8	•		✓	•					
	✓	•	•	•			•			IJ2				✓	•				
	✓	•	•	•			•			ID2		✓	•					•	•

1203-FM1 is only compatible with the 1203-FB1.



Allen-Bradley

Worldwide representation.

Publication 1794-7.2 - June 1998



PN955133-18

Copyright 1998 Allen-Bradley Company, Inc. Printed in USA