



Cat. No. Listing of Bulletin 194C, 194E, and 194L Control and Load Switches

Cross-Reference

Sprecher+Schuh L1 To Allen-Bradley Bulletin 194C

Description	Cat. No. Sprecher+Schuh L1	Cat. No. Allen-Bradley Bulletin 194C
ON-OFF SWITCH 0-1 1P	LC1-10-1501	194C-C10-1501
ON-OFF SWITCH 0-1 2P	LC1-10-1502	194C-C10-1502
ON-OFF SWITCH 0-1 3P	LC1-10-1503	194C-C10-1503
ON-OFF SWITCH 0-1 4P	LC1-10-1504	194C-C10-1504
ON-OFF SWITCH 0-1 5P	LC1-10-1505	194C-C10-1505
ON-OFF SWITCH 0-1 6P	LC1-10-1506	194C-C10-1506
ON-OFF SWITCH 0-1 1P	LC1-10-1751	194C-C10-1751
ON-OFF SWITCH 0-1 2P	LC1-10-1752	194C-C10-1752
ON-OFF SWITCH 0-1 3P	LC1-10-1753	194C-C10-1753
ON-OFF SWITCH 0-1 4P	LC1-10-1754	194C-C10-1754
ON-OFF SWITCH 0-1 5P	LC1-10-1755	194C-C10-1755
ON-OFF SWITCH 0-1 6P	LC1-10-1756	194C-C10-1756
ON-OFF SWITCH 0-1 4P	LC1-10-1764	194C-C10-1764
CHANGEOVER 1-2 1P	LC1-10-2501	194C-C10-2501
CHANGEOVER 1-2 2P	LC1-10-2502	194C-C10-2502
CHANGEOVER 1-2 3P	LC1-10-2503	194C-C10-2503
CHANGEOVER 1-2 4P	LC1-10-2504	194C-C10-2504
CHANGEOVER 1-2 5P	LC1-10-2505	194C-C10-2505
CHANGEOVER 1>0<2 1P	LC1-10-3001	194C-C10-3001
CHANGEOVER 1>0<2 2P	LC1-10-3002	194C-C10-3002
CHANGEOVER 1>0<2 3P	LC1-10-3003	194C-C10-3003
CHANGEOVER 1-0-2 1P	LC1-10-3501	194C-C10-3501
CHANGEOVER 1-0-2 2P	LC1-10-3502	194C-C10-3502
CHANGEOVER 1-0-2 3P	LC1-10-3503	194C-C10-3503
CHANGEOVER 1-0-2 4P	LC1-10-3504	194C-C10-3504
STEP SWITCH 1-2-3 1P	LC1-10-4501	194C-C10-4501
STEP SWITCH 1-2-3 2P	LC1-10-4502	194C-C10-4502
STEP SWITCH 1-2-3 3P	LC1-10-4503	194C-C10-4503
STEP SWITCH 1-2-3-4 1P	LC1-10-4511	194C-C10-4511
STEP SWITCH 1-2-3-4 2P	LC1-10-4512	194C-C10-4512
STEP SWITCH 1-2-3-4 3P	LC1-10-4513	194C-C10-4513
STEP SWITCH 1-2-3-4-5 1P	LC1-10-4521	194C-C10-4521
STEP SWITCH 1-2-3-4-5-6 1P	LC1-10-4531	194C-C10-4531
STEP SWITCH 0-1-2-3-4 1P	LC1-10-5001	194C-C10-5001
STEP SWITCH 0-1-2-3-4 2P	LC1-10-5002	194C-C10-5002
STEP SWITCH 0-1-2-3-4 3P	LC1-10-5003	194C-C10-5003
STEP SWITCH 0...-5 1P	LC1-10-5011	194C-C10-5011
STEP SWITCH 1-2-3-4-5 2P	LC1-10-5012	194C-C10-5012
STEP SWITCH 0...-5 3P	LC1-10-5013	194C-C10-5013
STEP SWITCH 0-1-2...-6 1P	LC1-10-5021	194C-C10-5021
STEP SWITCH 0-1-2...-6 2P	LC1-10-5022	194C-C10-5022
STEP SWITCH 0-1-2-3 1P	LC1-10-5261	194C-C10-5261
STEP SWITCH 0-1-2-3 2P	LC1-10-5262	194C-C10-5262
STEP SWITCH 0-1-2-3 3P	LC1-10-5263	194C-C10-5263
STEP SWITCH 0-1-2 1P	LC1-10-5501	194C-C10-5501

Description	Cat. No. Sprecher+Schuh L1	Cat. No. Allen-Bradley Bulletin 194C
STEP SWITCH 0-1-2 2P	LC1-10-5502	194C-C10-5502
STEP SWITCH 0-1-2 3P	LC1-10-5503	194C-C10-5503
REVERSING 1-0<2 3P	LC1-10-7003	194C-C10-7003
STAR-DELTA 0-Y-D 3P	LC1-10-7503	194C-C10-7503
DAHLANDER 1-0-2 3P	LC1-10-7533	194C-C10-7533
REVERSING 1-0-2 3P	LC1-10-7543	194C-C10-7543
VOLTMETER TR-ST-RS-O-RN-SN-TN	LC1-10-8251	194C-C10-8251
VOLTMETER 0-RS-ST-TR	LC1-10-8271	194C-C10-8271
VOLTMETER 0-RN-SN-TN	LC1-10-8291	194C-C10-8291
AMMETER 0-1-2-3 1P	LC1-10-8751	194C-C10-8751
AMMETER 0-1-2-3 2P	LC1-10-8752	194C-C10-8752
AMMETER 1-2-3-4 1P	LC1-10-8761	194C-C10-8761
AMMETER 0-1 1P	LC1-10-8771	194C-C10-8771
ON-OFF SWITCH <START 1P	LC1-10-9001	194C-C10-9001
ON-OFF SWITCH STOP> 1P	LC1-10-9011	194C-C10-9011
ON-OFF SWITCH STOP><START 1P	LC1-10-9021	194C-C10-9021
ON-OFF SWITCH 0-1<START 1P	LC1-10-9751	194C-C10-9751
ACTUATOR WITH KEY DA	LFC1-DA-001	194C-HCDA-001
ACTUATOR WITH KEY DB	LFC1-DB-001	194C-HCDB-001
ACTUATOR WITH KEY DF	LFC1-DF-001	194C-HCDF-001
ACTUATOR WITH KEY ROUND	LFC1-DG-001	194C-HCDG-001
ACTUATOR NEUTRAL	LFC1-B-001	194C-HCB-001
STANDARD BLACK KNOB	L1-G 3381	194C-G3381
NAMEPLATE HOLDER	L1-G 3383	194C-G3383
NAMEPLATE HOLDER	L1-G 3382	194C-G3382
ACTUATOR A 30X30 W/O LEG.PL.	LFC1-.-3	194C-HC3.
ACTUATOR A 30X30 0-1	LFC1-A-3-150	194C-HC3A-150
ACTUATOR A 30X30 0-1	LFC1-A-3-175	194C-HC3A-175
ACTUATOR A 30X30 OFF-ON	LFC1-A-3-175 I	194C-HC3A-175I
ACTUATOR A 30X30 0-1	LFC1-A-3-178	194C-HC3A-178
ACTUATOR A 30X30 1-2	LFC1-A-3-250	194C-HC3A-250
ACTUATOR A 30X30 1>0<2	LFC1-A-3-300	194C-HC3A-300
ACTUATOR A 30X30 1-0-2	LFC1-A-3-350	194C-HC3A-350
ACTUATOR A 30X30 1-2-3	LFC1-A-3-450	194C-HC3A-450
ACTUATOR A 30X30 1-2-3-4	LFC1-A-3-451	194C-HC3A-451
ACTUATOR A 30X30 1-2-3-4-5	LFC1-A-3-452	194C-HC3A-452
ACTUATOR A 30X30 1-2-3-4-5-6	LFC1-A-3-453	194C-HC3A-453
ACTUATOR A 30X30 0-1-2-3-4	LFC1-A-3-500	194C-HC3A-500
ACTUATOR A 30X30 0-.-5	LFC1-A-3-501	194C-HC3A-501
ACTUATOR A 30X30 0-1-2-3-4-5-6	LFC1-A-3-502	194C-HC3A-502
ACTUATOR A 30X30 0-1-2-3	LFC1-A-3-526	194C-HC3A-526
ACTUATOR A 30X30 0-1-2	LFC1-A-3-550	194C-HC3A-550
ACTUATOR A 30X30 0-Y-D	LFC1-A-3-750	194C-HC3A-750
AC.A 30X30 TR-ST-RS-0-RN-SN-TN	LFC1-A-3-825	194C-HC3A-825
ACTUATOR A 30X30 0-RS-ST-TR	LFC1-A-3-827	194C-HC3A-827
ACTUATOR A 30X30 0-RN-SN-TN	LFC1-A-3-829	194C-HC3A-829
ACTUATOR A 30X30 0-1-2-3	LFC1-A-3-875	194C-HC3A-875
ACTUATOR A 30X30 1-2-3-4	LFC1-A-3-876	194C-HC3A-876
ACTUATOR A 30X30 <START	LFC1-A-3-900	194C-HC3A-900
ACTUATOR A 30X30 STOP	LFC1-A-3-901	194C-HC3A-901
ACTUATOR A 30X30 STOP><START	LFC1-A-3-902	194C-HC3A-902
ACTUATOR A 30X30 0-1<START	LFC1-A-3-975	194C-HC3A-975
ACTUATOR WITH KEY W/O LEG.PL.	LFC1-CA-3	194C-HC3CA

Description	Cat. No. Sprecher+Schuh L1	Cat. No. Allen-Bradley Bulletin 194C
ACTUATOR WITH KEY W/O LEG.PL.	LFC1-CB-3	194C-HC3CB
ACTUATOR WITH KEY W/O LEG.PL.	LFC1-CF-3	194C-HC3CF
ACTUATOR WITH KEY W/O LEG.PL.	LFC1-CG-3	194C-HC3CG
ACTUATOR WITH KEY CA 30X30 0-1	LFC1-CA-3-175	194C-HC3CA-175
ACTUATOR WITH KEY 30X30 0-1	LFC1-CF-3-175	194C-HC3CF-175
ACTUATOR WITH KEY CA 30X30 1>0<2	LFC1-CA-3-300	194C-HC3CA-300
ACTUATOR WITH KEY CA30X30 1-2- 3	LFC1-CA-3-350	194C-HC3CA-350
ACTUATOR WITH KEY CG 1-2-3-4	LFC1-CG-3-451	194C-HC3CA-451
ACTUAT. WITH KEY CB 30X30 0-1-2	LFC1-CB-3-550	194C-HC3CA-550
LEGEND PLATE 30X30 NEUTRAL	LL1-A-3-000	194C-A3-000
LEGEND PLATE 30X30 0-1	LL1-A-3-150	194C-A3-150
LEGEND PLATE 30X30 1-2	LL1-A-3-250	194C-A3-250
LEGEND PLATE A 30X30 HAND-0- AUTO	LL1-A-3-350A	194C-A3-350A
LEGEND PLATE 30X30 0-1-2-3	LL1-A-3-875	194C-A3-875
LEGEND PLATE 30X30 NEUTRAL	LL1-C-3	194C-C3
LEGEND PLATE 30X30 0-1	LL1-CA-3-150	194C-CA3-150
LEGEND PLATE 30X30 0-1	LL1-CA-3-175	194C-CA3-175
LEGEND PLATE 30X30 1-0-2	LL1-CA-3-350	194C-CA3-350
LEGEND PLATE A 30X30 HAND-0- AUTO	LL1-C-3-350A	194C-CA3-350A
LEGEND PLATE 30X30 1-2-3-4	LL1-C-3-451	194C-C3-451
LEGEND PLATE 30X30 0-1-2-3-4	LL1-C-3-500	194C-C3-500
LEGEND PLATE 30X30 0-1-2-3	LL1-C-3-875	194C-C3-875
LEGEND PLATE 30X30 0-1 <START	LL1-C-3-975	194C-C3-975

L3/Bulletin 194E Series A to L7/Bulletin 194E Series B

Cross Reference

Description	Existing Cat. No.		New Cat. No.	
	Allen-Bradley Bulletin 194E Series A	Sprecher+Schuh L3	Allen-Bradley Bulletin 194E Series B	Spre- cher+Schuh L7
LOADSW. 20(25)A 0-1 3P BASE MOUNT.	194E-A20-1753	LA3-20-1753	194E-A25-1753	LA7-25-1753
LOADSW. 20(25)A 0-1 3P FRONT MOUNT.	194E-E20-1753	LE3-20-1753	194E-E25-1753	LE7-25-1753
LOADSW. 32A 0-1 3P BASE MOUNT.	194E-A32-1753	LA3-32-1753	194E-A32-1753	LA7-32-1753
LOADSW. 32A 0-1 3P FRONT MOUNT.	194E-E32-1753	LE3-32-1753	194E-E32-1753	LE7-32-1753
LOADSW. 40A 0-1 3P BASE MOUNT.	194E-A40-1753	LA3-40-1753	194E-A40-1753	LA7-40-1753
LOADSW. 40A 0-1 3P FRONT MOUNT.	194E-E40-1753	LE3-40-1753	194E-E40-1753	LE7-40-1753
LOADSW. 63A 0-1 3P BASE MOUNT.	194E-A63-1753	LA3-63-1753	194E-A63-1753	LA7-63-1753
LOADSW. 63A 0-1 3P FRONT MOUNT.	194E-E63-1753	LE3-63-1753	194E-E63-1753	LE7-63-1753
LOADSW. 80A 0-1 3P BASE MOUNT.	194E-A80-1753	LA3-80-1753	194E-A80-1753	LA7-80-1753
LOADSW. 80A 0-1 3P FRONT MOUNT.	194E-E80-1753	LE3-80-1753	194E-E80-1753	LE7-80-1753
LOADSW. 100A 0-1 3P BASE MOUNT.	194E-A00-1753	LA3-100-1753	194E-A100-1753	LA7-100-1753
LOADSW. 100A 0-1 3P FRONT MOUNT.	194E-E00-1753	LE3-100-1753	194E-E100-1753	LE7-100-1753
LOADSW. 20(25)A 0-1 6P BASE MOUNT.	194E-A20-1756	LA3-20-1756	194E-A25-1756	LA7-25-1756
LOADSW. 20(25)A 0-1 6P FRONT MOUNT.	194E-E20-1756	LE3-20-1756	194E-E25-1756	LE7-25-1756
LOADSW. 32A 0-1 6P BASE MOUNT.	194E-A32-1756	LA3-32-1756	194E-A32-1756	LA7-32-1756
LOADSW. 32A 0-1 6P FRONT MOUNT.	194E-E32-1756	LE3-32-1756	194E-E32-1756	LE7-32-1756
LOADSW. 40A 0-1 6P BASE MOUNT.	194E-A40-1756	LA3-40-1756	194E-A40-1756	LA7-40-1756
LOADSW. 40A 0-1 6P FRONT MOUNT.	194E-E40-1756	LE3-40-1756	194E-E40-1756	LE7-40-1756
LOADSW. 63A 0-1 6P BASE MOUNT.	194E-A63-1756	LA3-63-1756	194E-A63-1756	LA7-63-1756
LOADSW. 63A 0-1 6P FRONT MOUNT.	194E-E63-1756	LE3-63-1756	194E-E63-1756	LE7-63-1756
MAIN/EMERG.SW. 32A 0-1 3P BASE M.	Not available	LA3-32-1753/N-6	194E-A32-1753-6N	LA7-32-1753-N6
MAIN/EMER.SW. 32A 0-1 3P FRONT M.	Not available	LE3-32-1753/N-6	194E-E32-1753-6N	LE7-32-1753-N6
MAIN/EMERG.SW. 40A 0-1 3P BASE M.	Not available	LA3-40-1753/N-6	194E-A40-1753-6N	LA7-40-1753-N6
MAIN/EMER.SW. 40A 0-1 3P FRONT M.	Not available	LE3-40-1753/N-6	194E-E40-1753-6N	LE7-40-1753-N6

Description	Existing Cat. No.		New Cat. No.	
	Allen-Bradley Bulletin 194E Series A	Sprecher+Schuh L3	Allen-Bradley Bulletin 194E Series B	Sprecher+Schuh L7
MAIN/EMERG.SW. 63A 0-1 3P BASE M.	Not available	LA3-63-1753/N-6	194E-A63-1753-6N	LA7-63-1753-N6
MAIN/EMER.SW. 63A 0-1 3P FRONT M.	Not available	LE3-63-1753/N-6	194E-E63-1753-6N	LE7-63-1753-N6
MAIN/EMERG.SW. 80A 0-1 3P BASE M.	Not available	LA3-80-1753/N-6	194E-A80-1753-6N	LA7-80-1753-N6
MAIN/EMER.SW. 80A 0-1 3P FRONT M.	Not available	LE3-80-1753/N-6	194E-E80-1753-6N	LE7-80-1753-N6
MAIN/EMERG.SW.100A 0-1 3P BASE M.	Not available	LA3-100-1753/N-6	194E-A100-1753-6N	LA7-100-1753-N6
MAIN/EMER.SW.100A 0-1 3P FRONT M.	Not available	LE3-100-1753/N-6	194E-E100-1753-6N	LE7-100-1753-N6
LOADSW. ENCL. 32A 0-1 3P	Not available	LY3-32-1753-N	194E-Y32-1753-6N	LY7-32-1753-N6
LOADSW. ENCL. 40A 0-1 3P	Not available	LY3-40-1753-N	194E-Y40-1753-6N	LY7-40-1753-N6
LOADSW. ENCL. 63A 0-1 3P	Not available	LY3-63-1753-N	194E-Y63-1753-6N	LY7-63-1753-N6
LOADSW. ENCL. 80A 0-1 3P	Not available	LY3-80-1753-N	194E-Y80-1753-6N	LY7-80-1753-N6
LOADSW. ENCL. 100A 0-1 3P	Not available	LY3-100-1753-N	194E-Y100-1753-6N	LY7-100-1753-N6
LOADSW. ENCL. 32A 0-1 6P	Not available	LY3-32-1756-N	194E-Y32-1756-6N	LY7-32-1756-N6
LOADSW. ENCL. 40A 0-1 6P	Not available	LY3-40-1756-N	194E-Y40-1756-6N	LY7-40-1756-N6
LOADSW. ENCL. 63A 0-1 6P	Not available	LY3-63-1756-N	194E-Y63-1756-6N	LY7-63-1756-N6
4TH POLE NP FOR 20(25)A BASE MOUNT.	194E-A20-NP	LA3-20-NP	194E-A25-NP	LA7-25-NP
4TH POLE NP FOR 20(25)A FRONT MOUNT.	194E-E20-NP	LE3-20-NP	194E-E25-NP	LE7-25-NP
4TH POLE NP FOR 32A BASE MOUNT.	194E-A32-NP	LA3-32-NP	194E-A32-NP	LA7-32-NP
4TH POLE NP FOR 32E FRONT MOUNT.	194E-E32-NP	LE3-32-NP	194E-E32-NP	LE7-32-NP
4TH POLE NP FOR 40A BASE MOUNT.	194E-A40-NP	LA3-40-NP	194E-A40-NP	LA7-40-NP
4TH POLE NP FOR 40A FRONT MOUNT.	194E-E40-NP	LE3-40-NP	194E-E40-NP	LE7-40-NP
4TH POLE NP FOR 63A BASE MOUNT.	194E-A63-NP	LA3-63-NP	194E-A63-NP	LA7-63-NP
4TH POLE NP FOR 63A FRONT MOUNT.	194E-E63-NP	LE3-63-NP	194E-E63-NP	LE7-63-NP
4TH POLE NP FOR 80A BASE MOUNT.	194E-A80-NP	LA3-80-NP	194E-A80-NP	LA7-80-NP
4TH POLE NP FOR 80A FRONT MOUNT.	194E-E80-NP	LE3-80-NP	194E-E80-NP	LE7-80-NP
4TH POLE NP FOR 100A BASE MOUNT.	194E-A00-NP	LA3-100-NP	194E-A100-NP	LA7-100-NP
4TH POLE NP FOR 100A FRONT M.	194E-E00-NP	LE3-100-NP	194E-E100-NP	LE7-100-NP
EARTH TERM. FOR 20(25)/32A BASE M.	194E-A20-PE	L3-20-PE	194E-A32-PE	LA7-32-PE
EARTH TERM.FOR 20(25)/32A FRONT M.	194E-A20-PE	L3-20-PE	194E-E32-PE	LE7-32-PE
EARTH TERM. FOR 40/63A BASE M.	194E-A40-PE	L3-40-PE	194E-A63-PE	LA7-63-PE

Description	Existing Cat. No.		New Cat. No.	
	Allen-Bradley Bulletin 194E Series A	Sprecher+Schuh L3	Allen-Bradley Bulletin 194E Series B	Sprecher+Schuh L7
EARTH TERM.FOR 40/63A FRONT M.	194E-A40-PE	L3-40-PE	194E-E63-PE	LE7-63-PE
EARTH TERM.FOR 80/100A BASE M.	194E-A80-PE	L3-80-PE	194E-A100-PE	LA7-100-PE
EARTH TER.FOR 80/100A FRONT M.	194E-A80-PE	L3-80-PE	194E-E100-PE	LE7-100-PE
NEUTR. TERM. FOR 20(25)/32A BASE M.	194E-A20-TN	L3-20-TN	194E-A32-TN	LA7-32-TN
NEUTR. TERM.FOR 20(25)/32A FRONT M.	194E-A20-TN	L3-20-TN	194E-E32-TN	LE7-32-TN
NEUTR. TERM. FOR 40/63A BASE M.	194E-A40-TN	L3-40-TN	194E-A63-TN	LA7-63-TN
NEUTR. TERM.FOR 40/63A FRONT M.	194E-A40-TN	L3-40-TN	194E-E63-TN	LE7-63-TN
NEUTR. TERM. FOR 80/100A BASE M.	194E-A80-TN	L3-80-TN	194E-A100-TN	LA7-100-TN
NEUTR. TERM.FOR 80/100A FRONT M.	194E-A80-TN	L3-80-TN	194E-E100-TN	LE7-100-TN
AUX. CONT. 1NO+1NC BASE MOUNT.	194E-A20-P11	LA3-20-P11	194E-A-P11	LA7-P-11
AUX. CONT. 1NO+1NC BASE MOUNT.	194E-A40-P11	LA3-40-P11	194E-A-P11	LA7-P-11
AUX. CONT. 1NO+1NC BASE MOUNT.	194E-A80-P11	LA3-80-P11	194E-A-P11	LA7-P-11
AUX.CONT. 1NO+1NC FRONT MOUNT.	194E-E20-P11	LE3-20-P11	194E-E-P11	LE7-P-11
AUX.CONT. 1NO+1NC FRONT MOUNT.	194E-E40-P11	LE3-40-P11	194E-E-P11	LE7-P-11
AUX.CONT. 1NO+1NC FRONT MOUNT.	194E-E80-P11	LE3-80-P11	194E-E-P11	LE7-P-11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-A20-PL11	LA3-20-PL11	194E-A-PL11	LA7-P-L11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-A40-PL11	LA3-40-PL11	194E-A-PL11	LA7-P-L11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-A80-PL11	LA3-80-PL11	194E-A-PL11	LA7-P-L11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-E20-PL11	LE3-20-PL11	194E-E-PL11	LE7-P-L11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-E40-PL11	LE3-40-PL11	194E-E-PL11	LE7-P-L11
AUX.CONT. 1NO+1NC MAKE B.BREAK	194E-E80-PL11	LE3-80-PL11	194E-E-PL11	LE7-P-L11
TERMINAL COVER 3P FOR 20(25)/32A	194E-E20-C3	L3-20-C3	194E-25-C3	L7-25-C3
TERMINAL COVER 3P FOR 40/63A	194E-E40-C3	L3-40-C3	194E-40-C3	L7-40-C3
TERMINAL COVER 3P FOR 80/100A	194E-E80-C3	L3-80-C3	194E-80-C3	L7-80-C3
TERMINAL COVER 4P FOR 20(25)/32A	194E-E20-C4	L3-20-C4	194E-25-C4	L7-25-C4
TERMINAL COVER 4P FOR 40/63A	194E-E40-C4	L3-40-C4	194E-40-C4	L7-40-C4
TERMINAL COVER 4P FOR 80/100A	194E-E80-C4	L3-80-C4	194E-80-C4	L7-80-C4

**Cross Reference
Sprecher+Schuh L2 to Allen-Bradley Bulletin 194L**

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LE2-12-1753-N6	194L-E12-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LE2-12-1754-N6	194L-E12-1754-6N
ON-OFF SWITCH 0-1 1P	LE2-12-1501	194L-E12-1501
ON-OFF SWITCH 0-1 2P	LE2-12-1502	194L-E12-1502
ON-OFF SWITCH 0-1 3P	LE2-12-1503	194L-E12-1503
ON-OFF SWITCH 0-1 4P	LE2-12-1504	194L-E12-1504
ON-OFF SWITCH 0-1 5P	LE2-12-1505	194L-E12-1505
ON-OFF SWITCH 0-1 6P	LE2-12-1506	194L-E12-1506
ON-OFF SWITCH 0-1 1P	LE2-12-1751	194L-E12-1751
ON-OFF SWITCH 0-1 2P	LE2-12-1752	194L-E12-1752
ON-OFF SWITCH 0-1 3P	LE2-12-1753	194L-E12-1753
ON-OFF SWITCH 0-1 4P	LE2-12-1754	194L-E12-1754
ON-OFF SWITCH 0-1 5P	LE2-12-1755	194L-E12-1755
ON-OFF SWITCH 0-1 6P	LE2-12-1756	194L-E12-1756
ON-OFF SWITCH 0-1 4P	LE2-12-1764	194L-E12-1764
ON-OFF SWITCH 0-1 5P	LE2-12-1765	194L-E12-1765
ON-OFF SWITCH 0-1 4P	LE2-12-1774	194L-E12-1774
ON-OFF SWITCH 0-1 1P	LE2-12-1781	194L-E12-1781
ON-OFF SWITCH 0-1 2P	LE2-12-1782	194L-E12-1782
ON-OFF SWITCH 0-1 3P	LE2-12-1783	194L-E12-1783
ON-OFF SWITCH 0-1 4P	LE2-12-1784	194L-E12-1784
CHANGEOVER 1-2 1P	LE2-12-2251	194L-E12-2251
CHANGEOVER 1-2 2P	LE2-12-2252	194L-E12-2252
CHANGEOVER 1-2 3P	LE2-12-2253	194L-E12-2253
CHANGEOVER 1-2 4P	LE2-12-2254	194L-E12-2254
CHANGEOVER 1-2 5P	LE2-12-2255	194L-E12-2255
CHANGEOVER 1-2 1P	LE2-12-2501	194L-E12-2501
CHANGEOVER 1-2 2P	LE2-12-2502	194L-E12-2502
CHANGEOVER 1-2 3P	LE2-12-2503	194L-E12-2503
CHANGEOVER 1-2 4P	LE2-12-2504	194L-E12-2504
CHANGEOVER 1-2 5P	LE2-12-2505	194L-E12-2505
CHANGEOVER 1-0-2 1P	LE2-12-3001	194L-E12-3001
CHANGEOVER 1-0-2 2P	LE2-12-3002	194L-E12-3002
CHANGEOVER 1-0-2 3P	LE2-12-3003	194L-E12-3003
CHANGEOVER 1-0-2 1P	LE2-12-3251	194L-E12-3251
CHANGEOVER 1-0-2 2P	LE2-12-3252	194L-E12-3252
CHANGEOVER 1-0-2 3P	LE2-12-3253	194L-E12-3253
CHANGEOVER 1-0-2 4P	LE2-12-3254	194L-E12-3254
CHANGEOVER 1>0<2 1P	LE2-12-3261	194L-E12-3261
CHANGEOVER 1>0<2 2P	LE2-12-3262	194L-E12-3262
CHANGEOVER 1>0<2 3P	LE2-12-3263	194L-E12-3263
CHANGEOVER 1-0-2 1P	LE2-12-3501	194L-E12-3501
CHANGEOVER 1-0-2 2P	LE2-12-3502	194L-E12-3502
CHANGEOVER 1-0-2 3P	LE2-12-3503	194L-E12-3503
CHANGEOVER 1-0-2 4P	LE2-12-3504	194L-E12-3504
CHANGEOVER 1-0-2 1P	LE2-12-3751	194L-E12-3751
CHANGEOVER 1-0-2 2P	LE2-12-3752	194L-E12-3752
CHANGEOVER 1-0-2 3P	LE2-12-3753	194L-E12-3753

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
CHANGEOVER 1-0-2 4P	LE2-12-3754	194L-E12-3754
STEP SWITCH 1-2-3 1P	LE2-12-4251	194L-E12-4251
STEP SWITCH 1-2-3 2P	LE2-12-4252	194L-E12-4252
STEP SWITCH 1-2-3 3P	LE2-12-4253	194L-E12-4253
STEP SWITCH 1-2-3-4 1P	LE2-12-4261	194L-E12-4261
STEP SWITCH 1-2-3-4 2P	LE2-12-4262	194L-E12-4262
STEP SWITCH 1-2-3-4 3P	LE2-12-4263	194L-E12-4263
STEP SWITCH 1-2-3-4-5 1P	LE2-12-4271	194L-E12-4271
STEP SWITCH 1-2-3-4-5-6 1P	LE2-12-4281	194L-E12-4281
STEP SWITCH 1-2-3 1P	LE2-12-4291	194L-E12-4291
STEP SWITCH 1-2-3-4 1P	LE2-12-4301	194L-E12-4301
STEP SWITCH 1-2-3-4 2P	LE2-12-4302	194L-E12-4302
STEP SWITCH 1-2-3-4 3P	LE2-12-4303	194L-E12-4303
STEP SWITCH 1-2-3-4-5-6 1P	LE2-12-4311	194L-E12-4311
STEP SWITCH 1-2-3 1P	LE2-12-4501	194L-E12-4501
STEP SWITCH 1-2-3 2P	LE2-12-4502	194L-E12-4502
STEP SWITCH 1-2-3 3P	LE2-12-4503	194L-E12-4503
STEP SWITCH 1-2-3-4 1P	LE2-12-4511	194L-E12-4511
STEP SWITCH 1-2-3-4 2P	LE2-12-4512	194L-E12-4512
STEP SWITCH 1-2-3-4 3P	LE2-12-4513	194L-E12-4513
STEP SWITCH 1-2-3-4-5 1P	LE2-12-4521	194L-E12-4521
STEP SWITCH 1-2-3-4-5-6 1P	LE2-12-4531	194L-E12-4531
STEP SWITCH 0-1-2-4 3P	LE2-12-5001	194L-E12-5001
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5002	194L-E12-5002
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5003	194L-E12-5003
STEP SWITCH 0-1-2-...5 1P	LE2-12-5011	194L-E12-5011
STEP SWITCH 0-1-2-...5 2P	LE2-12-5012	194L-E12-5012
STEP SWITCH 0-1-2-...5 3P	LE2-12-5013	194L-E12-5013
STEP SWITCH 0-1-2-...6 1P	LE2-12-5021	194L-E12-5021
STEP SWITCH 0-1-2-...6 2P	LE2-12-5022	194L-E12-5022
STEP SWITCH 0-1-2 1P	LE2-12-5251	194L-E12-5051
STEP SWITCH 0-1-2 2P	LE2-12-5252	194L-E12-5052
STEP SWITCH 0-1-2 3P	LE2-12-5253	194L-E12-5053
STEP SWITCH 0-1-2-3 1P	LE2-12-5261	194L-E12-5261
STEP SWITCH 0-1-2-3 2P	LE2-12-5262	194L-E12-5262
STEP SWITCH 0-1-2-3 3P	LE2-12-5263	194L-E12-5263
STEP SWITCH 0-1-2-3-4 1P	LE2-12-5271	194L-E12-5271
STEP SWITCH 0-1-2-3-4 2P	LE2-12-5272	194L-E12-5272
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5273	194L-E12-5273
STEP SWITCH 0-1-2-...5 1P	LE2-12-5281	194L-E12-5281
STEP SWITCH 0-1-2-...5 2P	LE2-12-5282	194L-E12-5282
STEP SWITCH 0-1-2-...5 3P	LE2-12-5283	194L-E12-5283
STEP SWITCH 0-1-2-...6 1P	LE2-12-5291	194L-E12-5291
STEP SWITCH 0-1-2-...6 2P	LE2-12-5292	194L-E12-5292
STEP SWITCH 0-1-2-3 1P	LE2-12-5301	194L-E12-5301
STEP SWITCH 0-1-2-3 2P	LE2-12-5302	194L-E12-5302
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5311	194L-E12-5311
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5312	194L-E12-5312
STEP SWITCH 0-1-2-...5 1P	LE2-12-5321	194L-E12-5321
STEP SWITCH 0-1-2-...6 1P	LE2-12-5331	194L-E12-5331
STEP SWITCH 0-1-2-...7 1P	LE2-12-5341	194L-E12-5341
STEP SWITCH 0-1-2 1P	LE2-12-5501	194L-E12-5501
STEP SWITCH 0-1-2 2P	LE2-12-5502	194L-E12-5502

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
STEP SWITCH 0-1-2 3P	LE2-12-5503	194L-E12-5503
STEP SWITCH 0-1-2-3 1P	LE2-12-5511	194L-E12-5511
STEP SWITCH 0-1-2-3 2P	LE2-12-5512	194L-E12-5512
STEP SWITCH 0-1-2-3 3P	LE2-12-5513	194L-E12-5513
STEP SWITCH 0-1-2-3-4 1P	LE2-12-5521	194L-E12-5521
STEP SWITCH 0-1-2-3-4 2P	LE2-12-5522	194L-E12-5522
STEP SWITCH 0-1-2-3-4 3P	LE2-12-5523	194L-E12-5523
STEP SWITCH 0-1-2...5 1P	LE2-12-5531	194L-E12-5531
STEP SWITCH 0-1-2...5 2P	LE2-12-5532	194L-E12-5532
STEP SWITCH 0-1-2...5 3P	LE2-12-5533	194L-E12-5533
GROUP SWITCH 0-1-2-3 1P	LE2-12-6001	194L-E12-6001
GROUP SWITCH 0-1-2 1P	LE2-12-6501	194L-E12-6501
GROUP SWITCH 0-1-2-3 1P	LE2-12-6511	194L-E12-6511
REVERSING SWITCH 1>0<2 3P	LE2-12-7003	194L-E12-7003
STAR-DELTA 0-Y-D 3P	LE2-12-7253	194L-E12-7253
STAR-DELTA D-Y-0-Y-D 3P	LE2-12-7283	194L-E12-7283
DAHLANDER 1-0-2 3P	LE2-12-7293	194L-E12-7293
REVERSING SWITCH 1-0-2 3P	LE2-12-7303	194L-E12-7303
REVERSING SWITCH 1>0<2 3P	LE2-12-7313	194L-E12-7313
STAR-DELTA 0-Y-D 3P	LE2-12-7323	194L-E12-7323
STARTERS 0-M-A 2P	LE2-12-7332	194L-E12-7332
REVERSING SWITCH A-M-0-M-A 2P	LE2-12-7342	194L-E12-7342
REVERSING SWITCH 1-0-2 2P	LE2-12-7352	194L-E12-7352
STAR-DELTA 0-Y-D 3P	LE2-12-7503	194L-E12-7503
STAR-DELTA D-Y-0-Y-D 3P	LE2-12-7513	194L-E12-7513
DAHLANDER 0-1-2 3P	LE2-12-7523	194L-E12-7523
DAHLANDER 1-0-2 3P	LE2-12-7533	194L-E12-7533
REVERSING 1-0-2 3P	LE2-12-7543	194L-E12-7543
STAR-DELTA 0-Y-D 3P	LE2-12-7553	194L-E12-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-12-8001	194L-E12-8001
VOLTMETER 0-RS-ST-TR	LE2-12-8021	194L-E12-8021
VOLTMETER 0-RN-SN-TN	LE2-12-8031	194L-E12-8031
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-12-8251	194L-E12-8251
VOLTMETER 0-RS-ST-TR-0	LE2-12-8261	194L-E12-8261
VOLTMETER 0-RS-ST-TR	LE2-12-8271	194L-E12-8271
VOLTMETER 0-RN-SN-TN-0	LE2-12-8281	194L-E12-8281
VOLTMETER 0-RN-SN-TN	LE2-12-8291	194L-E12-8291
VOLTMETER 0-RS-ST-TR-0	LE2-12-8302	194L-E12-8302
VOLTMETER 0-RN-SN-TN-0	LE2-12-8312	194L-E12-8312
VOLTMETER 0-RS-.0-R1S1-.T1R1	LE2-12-8322	194L-E12-8322
VOLTMETER RN-0-RS-ST-TR	LE2-12-8332	194L-E12-8332
AMMETER 0-1-2-3 1P	LE2-12-8751	194L-E12-8751
AMMETER 0-1-2-3 2P	LE2-12-8752	194L-E12-8752
AMMETER 1-2-3-4 1P	LE2-12-8761	194L-E12-8761
AMMETER 0-1 1P	LE2-12-8771	194L-E12-8771
ON-OFF SWITCH <START 1P	LE2-12-9001	194L-E12-9001
ON-OFF SWITCH STOP> 1P	LE2-12-9011	194L-E12-9011
ON-OFF SWIT. STOP><START 1P	LE2-12-9021	194L-E12-9021
ON-OFF SWIT. STOP><START 1P	LE2-12-9251	194L-E12-9251
ON-OFF SWITCH 0-1<START 1P	LE2-12-9751	194L-E12-9751
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LA2-12-1753-N6	194L-A12-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LA2-12-1754-N6	194L-A12-1754-6N

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ON-OFF SWITCH 0-1 1P	LA2-12-1501	194L-A12-1501
ON-OFF SWITCH 0-1 2P	LA2-12-1502	194L-A12-1502
ON-OFF SWITCH 0-1 3P	LA2-12-1503	194L-A12-1503
ON-OFF SWITCH 0-1 4P	LA2-12-1504	194L-A12-1504
ON-OFF SWITCH 0-1 5P	LA2-12-1505	194L-A12-1505
ON-OFF SWITCH 0-1 6P	LA2-12-1506	194L-A12-1506
ON-OFF SWITCH 0-1 1P	LA2-12-1751	194L-A12-1751
ON-OFF SWITCH 0-1 2P	LA2-12-1752	194L-A12-1752
ON-OFF SWITCH 0-1 3P	LA2-12-1753	194L-A12-1753
ON-OFF SWITCH 0-1 4P	LA2-12-1754	194L-A12-1754
ON-OFF SWITCH 0-1 5P	LA2-12-1755	194L-A12-1755
ON-OFF SWITCH 0-1 6P	LA2-12-1756	194L-A12-1756
ON-OFF SWITCH 0-1 4P	LA2-12-1764	194L-A12-1764
ON-OFF SWITCH 0-1 5P	LA2-12-1765	194L-A12-1765
ON-OFF SWITCH 0-1 4P	LA2-12-1774	194L-A12-1774
ON-OFF SWITCH 0-1 1P	LA2-12-1781	194L-A12-1781
ON-OFF SWITCH 0-1 2P	LA2-12-1782	194L-A12-1782
ON-OFF SWITCH 0-1 3P	LA2-12-1783	194L-A12-1783
ON-OFF SWITCH 0-1 4P	LA2-12-1784	194L-A12-1784
CHANGEOVER 1-2 1P	LA2-12-2251	194L-A12-2251
CHANGEOVER 1-2 2P	LA2-12-2252	194L-A12-2252
CHANGEOVER 1-2 3P	LA2-12-2253	194L-A12-2253
CHANGEOVER 1-2 4P	LA2-12-2254	194L-A12-2254
CHANGEOVER 1-0-2 1P	LA2-12-3251	194L-A12-3251
CHANGEOVER 1-0-2 2P	LA2-12-3252	194L-A12-3252
CHANGEOVER 1-0-2 3P	LA2-12-3253	194L-A12-3253
CHANGEOVER 1-0-2 4P	LA2-12-3254	194L-A12-3254
CHANGEOVER 1-0-2 3P	LA2-12-3503	194L-A12-3503
CHANGEOVER 1-0-2 4P	LA2-12-3504	194L-A12-3504
CHANGEOVER 1-0-2 3P	LA2-12-3753	194L-A12-3753
STEP SWITCH 1-2-3 1P	LA2-12-4251	194L-A12-4251
STEP SWITCH 1-2-3-4 1P	LA2-12-4261	194L-A12-4261
STEP SWITCH 1-2-3-4-5 1P	LA2-12-4271	194L-A12-4271
STEP SWITCH 1-2-3-4-5-6 1P	LA2-12-4281	194L-A12-4281
STEP SWITCH 0-1-2-3 1P	LA2-12-5261	194L-A12-5261
STEP SWITCH 0-1-2-3-4 1P	LA2-12-5271	194L-A12-5271
STEP SWITCH 0-1-2-...5 1P	LA2-12-5281	194L-A12-5281
STEP SWITCH 0-1-2-...6 1P	LA2-12-5291	194L-A12-5291
STAR-DELTA 0-Y-D 3P	LA2-12-7253	194L-A12-7253
DAHLANDER 1-0-2 3P	LA2-12-7293	194L-A12-7293
REVERSING 1-0-2 3P	LA2-12-7303	194L-A12-7303
REVERSING 1>0<2 3P	LA2-12-7313	194L-A12-7313
STAR-DELTA 0-Y-D 3P	LA2-12-7323	194L-A12-7323
STAR-DELTA 0-Y-D 3P	LA2-12-7553	194L-A12-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LA2-12-8251	194L-A12-8251
VOLTMETER 0-RS-ST-TR-0	LA2-12-8261	194L-A12-8261
VOLTMETER 0-RS-ST-TR	LA2-12-8271	194L-A12-8271
VOLTMETER 0-RN-SN-TN-0	LA2-12-8281	194L-A12-8281
VOLTMETER 0-RN-SN-TN	LA2-12-8291	194L-A12-8291
VOLTMETER 0-RS-ST-TR-0	LA2-12-8302	194L-A12-8302
VOLTMETER 0-RN-SN-TN-0	LA2-12-8312	194L-A12-8312
VOLTMETER 0-RS-.0-R1S1-.T1R1	LA2-12-8322	194L-A12-8322
VOLTMETER*RN-0-RS-ST-TR-*12A	LA2-12-8332	194L-A12-8332

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
AMMETER 0-1-2-3 1P	LA2-12-8751	194L-A12-8751
AMMETER 0-1-2-3 2P	LA2-12-8752	194L-A12-8752
AMMETER 1-2-3-4 1P	LA2-12-8761	194L-A12-8761
AMMETER 0-1 1P	LA2-12-8771	194L-A12-8771
ON-OFF SWITCH <START 1P	LA2-12-9001	194L-A12-9001
ON-OFF SWITCH STOP> 1P	LA2-12-9011	194L-A12-9011
ON-OFF SWITCH STOP><START 1P	LA2-12-9021	194L-A12-9021
ON-OFF SWITCH STOP><START 1P	LA2-12-9251	194L-A12-9251
ON-OFF SWITCH 0-1<START 1P	LA2-12-9751	194L-A12-9751
MODULAR ON-OFF SWITCH 0-1 1P	LA2-12-1751-Q	194L-A12-1751-Q
MODULAR ON-OFF SWITCH 0-1 2P	LA2-12-1752-Q	194L-A12-1752-Q
MODULAR ON-OFF SWITCH 0-1 3P	LA2-12-1753-Q	194L-A12-1753-Q
MODULAR ON-OFF SWITCH 0-1 4P	LA2-12-1754-Q	194L-A12-1754-Q
MODULAR ON-OFF SWITCH 0-1 6P	LA2-12-1756-Q	194L-A12-1756-Q
MODULAR C/OV. SW.W/ O.LEG.PLATE	LA2-12-2251-Q	194L-A12-2251-Q
MODULAR C/OVER SWITCH 1-0-2 1P	LA2-12-3251-Q	194L-A12-3251-Q
MODULAR C/OVER SWITCH 1-0-2 2P	LA2-12-3252-Q	194L-A12-3252-Q
MODULAR C/OVER SWITCH 1-0-2 3P	LA2-12-3253-Q	194L-A12-3253-Q
MODULAR C/OV.SW.W/ O.LEG.PLATE	LA2-12-5301-Q	194L-A12-5301-Q
MODULAR AMM.SWITCH 0-1-2-3 1P	LA2-12-8751-Q	194L-A12-8751-Q
MOD.VOLTM.SWITCH TR-.0.-TN	LA2-12-8251-Q	194L-A12-8251-Q
MOD.VOLTM.SWITCH 0-RS-ST-TR-0	LA2-12-8261-Q	194L-A12-8261-Q
MOD.VOLTM.SWITCH 0-RS-ST-TR	LA2-12-8271-Q	194L-A12-8271-Q
MOD.VOLTM.SWITCH 0-RS-ST-TR-0	LA2-12-8302-Q	194L-A12-8302-Q
MOD.VOLTM.SWITCH L3-L1/./L3-N	LA2-12-8251-QA	194L-A12-8251-QA
MOD.VOLTM.SWITCH 0-L1-L2-L3-0	LA2-12-8261-QA	194L-A12-8261-QA
MOD.VOLTM.SWITCH L1-L2/./L3-L1	LA2-12-8271-QA	194L-A12-8271-QA
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LE2-16-1753-N6	194L-E16-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LE2-16-1754-N6	194L-E16-1754-6N
ON-OFF SWITCH 0-1 1P	LE2-16-1501	194L-E16-1501
ON-OFF SWITCH 0-1 2P	LE2-16-1502	194L-E16-1502
ON-OFF SWITCH 0-1 3P	LE2-16-1503	194L-E16-1503
ON-OFF SWITCH 0-1 4P	LE2-16-1504	194L-E16-1504
ON-OFF SWITCH 0-1 5P	LE2-16-1505	194L-E16-1505
ON-OFF SWITCH 0-1 6P	LE2-16-1506	194L-E16-1506
ON-OFF SWITCH 0-1 1P	LE2-16-1751	194L-E16-1751
ON-OFF SWITCH 0-1 2P	LE2-16-1752	194L-E16-1752
ON-OFF SWITCH 0-1 3P	LE2-16-1753	194L-E16-1753
ON-OFF SWITCH 0-1 4P	LE2-16-1754	194L-E16-1754
ON-OFF SWITCH 0-1 5P	LE2-16-1755	194L-E16-1755
ON-OFF SWITCH 0-1 6P	LE2-16-1756	194L-E16-1756
ON-OFF SWITCH 0-1 4P	LE2-16-1764	194L-E16-1764
ON-OFF SWITCH 0-1 5P	LE2-16-1765	194L-E16-1765
ON-OFF SWITCH 0-1 4P	LE2-16-1774	194L-E16-1774
ON-OFF SWITCH 0-1 1P	LE2-16-1781	194L-E16-1781
ON-OFF SWITCH 0-1 2P	LE2-16-1782	194L-E16-1782
ON-OFF SWITCH 0-1 3P	LE2-16-1783	194L-E16-1783
ON-OFF SWITCH 0-1 4P	LE2-16-1784	194L-E16-1784

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
CHANGEOVER 1-2 1P	LE2-16-2251	194L-E16-2251
CHANGEOVER 1-2 2P	LE2-16-2252	194L-E16-2252
CHANGEOVER 1-2 3P	LE2-16-2253	194L-E16-2253
CHANGEOVER 1-2 4P	LE2-16-2254	194L-E16-2254
CHANGEOVER 1-2 5P	LE2-16-2255	194L-E16-2255
CHANGEOVER 1-2 1P	LE2-16-2501	194L-E16-2501
CHANGEOVER 1-2 2P	LE2-16-2502	194L-E16-2502
CHANGEOVER 1-2 3P	LE2-16-2503	194L-E16-2503
CHANGEOVER 1-2 4P	LE2-16-2504	194L-E16-2504
CHANGEOVER 1-2 5P	LE2-16-2505	194L-E16-2505
CHANGEOVER 1-0-2 1P	LE2-16-3001	194L-E16-3001
CHANGEOVER 1-0-2 2P	LE2-16-3002	194L-E16-3002
CHANGEOVER 1-0-2 3P	LE2-16-3003	194L-E16-3003
CHANGEOVER 1-0-2 1P	LE2-16-3251	194L-E16-3251
CHANGEOVER 1-0-2 2P	LE2-16-3252	194L-E16-3252
CHANGEOVER 1-0-2 3P	LE2-16-3253	194L-E16-3253
CHANGEOVER 1-0-2 4P	LE2-16-3254	194L-E16-3254
CHANGEOVER 1>0<2 1P	LE2-16-3261	194L-E16-3261
CHANGEOVER 1>0<2 2P	LE2-16-3262	194L-E16-3262
CHANGEOVER 1>0<2 3P	LE2-16-3263	194L-E16-3263
CHANGEOVER 1-0-2 1P	LE2-16-3501	194L-E16-3501
CHANGEOVER 1-0-2 2P	LE2-16-3502	194L-E16-3502
CHANGEOVER 1-0-2 3P	LE2-16-3503	194L-E16-3503
CHANGEOVER 1-0-2 4P	LE2-16-3504	194L-E16-3504
CHANGEOVER 1-0-2 1P	LE2-16-3751	194L-E16-3751
CHANGEOVER 1-0-2 2P	LE2-16-3752	194L-E16-3752
CHANGEOVER 1-0-2 3P	LE2-16-3753	194L-E16-3753
CHANGEOVER 1-0-2 4P	LE2-16-3754	194L-E16-3754
STEP SWITCH 1-2-3 1P	LE2-16-4251	194L-E16-4251
STEP SWITCH 1-2-3 2P	LE2-16-4252	194L-E16-4252
STEP SWITCH 1-2-3 3P	LE2-16-4253	194L-E16-4253
STEP SWITCH 1-2-3-4 1P	LE2-16-4261	194L-E16-4261
STEP SWITCH 1-2-3-4 2P	LE2-16-4262	194L-E16-4262
STEP SWITCH 1-2-3-4 3P	LE2-16-4263	194L-E16-4263
STEP SWITCH 1-2-3-4-5 1P	LE2-16-4271	194L-E16-4271
STEP SWITCH 1-2-3-4-5-6 1P	LE2-16-4281	194L-E16-4281
STEP SWITCH 1-2-3 1P	LE2-16-4291	194L-E16-4291
STEP SWITCH 1-2-3-4 1P	LE2-16-4301	194L-E16-4301
STEP SWITCH 1-2-3-4 2P	LE2-16-4302	194L-E16-4302
STEP SWITCH 1-2-3-4 3P	LE2-16-4303	194L-E16-4303
STEP SWITCH 1-2-3-4-5-6 1P	LE2-16-4311	194L-E16-4311
STEP SWITCH 1-2-3 1P	LE2-16-4501	194L-E16-4501
STEP SWITCH 1-2-3 2P	LE2-16-4502	194L-E16-4502
STEP SWITCH 1-2-3 3P	LE2-16-4503	194L-E16-4503
STEP SWITCH 1-2-3-4 1P	LE2-16-4511	194L-E16-4511
STEP SWITCH 1-2-3-4 2P	LE2-16-4512	194L-E16-4512
STEP SWITCH 1-2-3-4 3P	LE2-16-4513	194L-E16-4513
STEP SWITCH 1-2-3-4-5 1P	LE2-16-4521	194L-E16-4521
STEP SWITCH 1-2-3-4-5-6 1P	LE2-16-4531	194L-E16-4531
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5001	194L-E16-5001
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5002	194L-E16-5002
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5003	194L-E16-5003
STEP SWITCH 0-1-2-...5 1P	LE2-16-5011	194L-E16-5011

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
STEP SWITCH 0-1-2-...5 2P	LE2-16-5012	194L-E16-5012
STEP SWITCH 0-1-2-...5 3P	LE2-16-5013	194L-E16-5013
STEP SWITCH 0-1-2-...6 1P	LE2-16-5021	194L-E16-5021
STEP SWITCH 0-1-2-...6 2P	LE2-16-5022	194L-E16-5022
STEP SWITCH 0-1-2 1P	LE2-16-5251	194L-E16-5251
STEP SWITCH 0-1-2 2P	LE2-16-5252	194L-E16-5252
STEP SWITCH 0-1-2 3P	LE2-16-5253	194L-E16-5253
STEP SWITCH 0-1-2-3 1P	LE2-16-5261	194L-E16-5261
STEP SWITCH 0-1-2-3 2P	LE2-16-5262	194L-E16-5262
STEP SWITCH 0-1-2-3 3P	LE2-16-5263	194L-E16-5263
STEP SWITCH 0-1-2-3-4 1P	LE2-16-5271	194L-E16-5271
STEP SWITCH 0-1-2-3-4 2P	LE2-16-5272	194L-E16-5272
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5273	194L-E16-5273
STEP SWITCH 0-1-2-...5 1P	LE2-16-5281	194L-E16-5281
STEP SWITCH 0-1-2-...5 2P	LE2-16-5282	194L-E16-5282
STEP SWITCH 0-1-2-...5 3P	LE2-16-5283	194L-E16-5283
STEP SWITCH 0-1-2-...6 1P	LE2-16-5291	194L-E16-5291
STEP SWITCH 0-1-2-...6 2P	LE2-16-5292	194L-E16-5292
STEP SWITCH 0-1-2-3 1P	LE2-16-5301	194L-E16-5301
STEP SWITCH 0-1-2-3 2P	LE2-16-5302	194L-E16-5302
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5311	194L-E16-5311
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5312	194L-E16-5312
STEP SWITCH 0-1-2-...5 1P	LE2-16-5321	194L-E16-5321
STEP SWITCH 0-1-2-...6 1P	LE2-16-5331	194L-E16-5331
STEP SWITCH 0-1-2-...7 1P	LE2-16-5341	194L-E16-5341
STEP SWITCH 0-1-2 1P	LE2-16-5501	194L-E16-5501
STEP SWITCH 0-1-2 2P	LE2-16-5502	194L-E16-5502
STEP SWITCH 0-1-2 3P	LE2-16-5503	194L-E16-5503
STEP SWITCH 0-1-2-3 1P	LE2-16-5511	194L-E16-5511
STEP SWITCH 0-1-2-3 2P	LE2-16-5512	194L-E16-5512
STEP SWITCH 0-1-2-3 3P	LE2-16-5513	194L-E16-5513
STEP SWITCH 0-1-2-3-4 1P	LE2-16-5521	194L-E16-5521
STEP SWITCH 0-1-2-3-4 2P	LE2-16-5522	194L-E16-5522
STEP SWITCH 0-1-2-3-4 3P	LE2-16-5523	194L-E16-5523
STEP SWITCH 0-1-2-...5 1P	LE2-16-5531	194L-E16-5531
STEP SWITCH 0-1-2-...5 2P	LE2-16-5532	194L-E16-5532
STEP SWITCH 0-1-2-...5 3P	LE2-16-5533	194L-E16-5533
GROUP SWITCH 0-1-2-3 1P	LE2-16-6001	194L-E16-6001
GROUP SWITCH 0-1-2 1P	LE2-16-6501	194L-E16-6501
GROUP SWITCH 0-1-2-3 1P	LE2-16-6511	194L-E16-6511
REVERSING 1>0<2 3P	LE2-16-7003	194L-E16-7003
STAR-DELTA 0-Y-D 3P	LE2-16-7253	194L-E16-7253
STAR DELTA D-Y-0-Y-D 3P	LE2-16-7283	194L-E16-7283
DAHLANDER 1-0-2 3P	LE2-16-7293	194L-E16-7293
REVERSING 1-0-2 3P	LE2-16-7303	194L-E16-7303
REVERSING 1>0<2 3P	LE2-16-7313	194L-E16-7313
STAR DELTA 0-Y-D 3P	LE2-16-7323	194L-E16-7323
STARTER 0-M-A 2P	LE2-16-7332	194L-E16-7332
REVERSING A-M-0-M-A 2P	LE2-16-7342	194L-E16-7342
REVERSING 1-0-2 2P	LE2-16-7352	194L-E16-7352
STAR DELTA 0-Y-D 3P	LE2-16-7503	194L-E16-7503
STAR DELTA D-Y-0-Y-D 3P	LE2-16-7513	194L-E16-7513
DAHLANDER 0-1-2 3P	LE2-16-7523	194L-E16-7523

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
DAHLANDER 1-0-2 3P	LE2-16-7533	194L-E16-7533
REVERSING 1-0-2 3P	LE2-16-7543	194L-E16-7543
STAR DELTA 0-Y-D 3P	LE2-16-7553	194L-E16-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-16-8001	194L-E16-8001
VOLTMETER 0-RS-ST-TR	LE2-16-8021	194L-E16-8021
VOLTMETER 0-RN-SN-TN	LE2-16-8031	194L-E16-8031
VOLTM. TR-ST-RS-0-RN-SN-TN	LE2-16-8251	194L-E16-8251
VOLTMETER 0-RS-ST-TR-0	LE2-16-8261	194L-E16-8261
VOLTMETER 0-RS-ST-TR	LE2-16-8271	194L-E16-8271
VOLTMETER 0-RN-SN-TN-0	LE2-16-8281	194L-E16-8281
VOLTMETER 0-RN-SN-TN	LE2-16-8291	194L-E16-8291
VOLTMETER 0-RS-ST-TR-0	LE2-16-8302	194L-E16-8302
VOLTMETER 0-RS-ST-TN-0	LE2-16-8312	194L-E16-8312
VOLTMETER 0-RS-.0-R1S1-.T1R1	LE2-16-8322	194L-E16-8322
VOLTMETER RN-0-RS-ST-TR	LE2-16-8332	194L-E16-8332
AMMETER 0-1-2-3 1P	LE2-16-8751	194L-E16-8751
AMMETER 0-1-2-3 2P	LE2-16-8752	194L-E16-8752
AMMETER 1-2-3-4 1P	LE2-16-8761	194L-E16-8761
AMMETER 0-1 1P	LE2-16-8771	194L-E16-8771
ON-OFF SWITCH <START 1P	LE2-16-9001	194L-E16-9001
ON-OFF SWITCH STOP> 1P	LE2-16-9011	194L-E16-9011
ON-OFF SWITCH STOP><START 1P	LE2-16-9021	194L-E16-9021
ON-OFF SWITCH STOP><START 1P	LE2-16-9251	194L-E16-9251
ON-OFF SWITCH 0-1<START 1P	LE2-16-9751	194L-E16-9751
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LA2-16-1753-N6	194L-A16-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LA2-16-1754-N6	194L-A16-1754-6N
ON-OFF SWITCH 0-1 1P	LA2-16-1501	194L-A16-1501
ON-OFF SWITCH 0-1 2P	LA2-16-1502	194L-A16-1502
ON-OFF SWITCH 0-1 3P	LA2-16-1503	194L-A16-1503
ON-OFF SWITCH 0-1 4P	LA2-16-1504	194L-A16-1504
ON-OFF SWITCH 0-1 5P	LA2-16-1505	194L-A16-1505
ON-OFF SWITCH 0-1 6P	LA2-16-1506	194L-A16-1506
ON-OFF SWITCH 0-1 1P	LA2-16-1751	194L-A16-1751
ON-OFF SWITCH 0-1 2P	LA2-16-1752	194L-A16-1752
ON-OFF SWITCH 0-1 3P	LA2-16-1753	194L-A16-1753
ON-OFF SWITCH 0-1 4P	LA2-16-1754	194L-A16-1754
ON-OFF SWITCH 0-1 5P	LA2-16-1755	194L-A16-1755
ON-OFF SWITCH 0-1 6P	LA2-16-1756	194L-A16-1756
ON-OFF SWITCH 0-1 4P	LA2-16-1764	194L-A16-1764
ON-OFF SWITCH 0-1 5P	LA2-16-1765	194L-A16-1765
ON-OFF SWITCH 0-1 4P	LA2-16-1774	194L-A16-1774
ON-OFF SWITCH 0-1 1P	LA2-16-1781	194L-A16-1781
ON-OFF SWITCH 0-1 2P	LA2-16-1782	194L-A16-1782
ON-OFF SWITCH 0-1 3P	LA2-16-1783	194L-A16-1783
ON-OFF SWITCH 0-1 4P	LA2-16-1784	194L-A16-1784
CHANGEOVER 1-2 1P	LA2-16-2251	194L-A16-2251
CHANGEOVER 1-2 2P	LA2-16-2252	194L-A16-2252
CHANGEOVER 1-2 3P	LA2-16-2253	194L-A16-2253
CHANGEOVER 1-2 4P	LA2-16-2254	194L-A16-2254
CHANGEOVER 1-0-2 1P	LA2-16-3251	194L-A16-3251
CHANGEOVER 1-0-2 2P	LA2-16-3252	194L-A16-3252
CHANGEOVER 1-0-2 3P	LA2-16-3253	194L-A16-3253

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
CHANGEOVER 1-0-2 4P	LA2-16-3254	194L-A16-3254
CHANGEOVER 1>0<2 3P	LA2-16-3263	194L-A16-3263
CHANGEOVER 1-0-2 3P	LA2-16-3503	194L-A16-3503
CHANGEOVER 1-0-2 4P	LA2-16-3504	194L-A16-3504
CHANGEOVER 1-0-2 3P	LA2-16-3753	194L-A16-3753
STEP SWITCH 1-2-3 1P	LA2-16-4251	194L-A16-4251
STEP SWITCH 1-2-3-4 1P	LA2-16-4261	194L-A16-4261
STEP SWITCH 1-2-3-4-5 1P	LA2-16-4271	194L-A16-4271
STEP SWITCH 1-2-3-4-5-6 1P	LA2-16-4281	194L-A16-4281
STEP SWITCH 0-1-2-3 1P	LA2-16-5261	194L-A16-5261
STEP SWITCH 0-1-2-3-4 1P	LA2-16-5271	194L-A16-5271
STEP SWITCH 0-1-2-...-5 1P	LA2-16-5281	194L-A16-5281
STEP SWITCH 0-1-2-...-6 1P	LA2-16-5291	194L-A16-5291
STAR-DELTA 0-Y-D 3P	LA2-16-7253	194L-A16-7253
DAHLANDER 1-0-2 3P	LA2-16-7293	194L-A16-7293
REVERSING 1-0-2 3P	LA2-16-7303	194L-A16-7303
REVERSING 1>0<2 3P	LA2-16-7313	194L-A16-7313
STAR-DELTA 0-Y-D 3P	LA2-16-7323	194L-A16-7323
STAR-DELTA 0-Y-D 3P	LA2-16-7553	194L-A16-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LA2-16-8251	194L-A16-8251
VOLTMETER 0-RS-ST-TR-0	LA2-16-8261	194L-A16-8261
VOLTMETER 0-RS-ST-TR	LA2-16-8271	194L-A16-8271
VOLTMETER 0-RN-SN-TN-0	LA2-16-8281	194L-A16-8281
VOLTMETER 0-RN-SN-TN	LA2-16-8291	194L-A16-8291
VOLTMETER 0-RS-ST-TR-0	LA2-16-8302	194L-A16-8302
VOLTMETER 0-RN-SN-TN-0	LA2-16-8312	194L-A16-8312
VOLTM. 0-RS-...-0-R1S1-...-T1R1	LA2-16-8322	194L-A16-8322
AMMETER 0-1-2-3 1P	LA2-16-8751	194L-A16-8751
AMMETER 1-2-3-4 1P	LA2-16-8761	194L-A16-8761
AMMETER 0-1 1P	LA2-16-8771	194L-A16-8771
ON-OFF SWITCH <START 1P	LA2-16-9001	194L-A16-9001
ON-OFF SWITCH STOP> 1P	LA2-16-9011	194L-A16-9011
ON-OFF SWITCH STOP><START 1P	LA2-16-9021	194L-A16-9021
ON-OFF SWITCH STOP><START 1P	LA2-16-9251	194L-A16-9251
ON-OFF SWITCH 0-1<START 1P	LA2-16-9751	194L-A16-9751
MODULAR ON-OFF SW. 0-1 1P	LA2-16-1751-Q	194L-A16-1751-Q
MODULAR ON-OFF SW. 0-1 2P	LA2-16-1752-Q	194L-A16-1752-Q
MODULAR ON-OFF SWITCH 0-1 3P	LA2-16-1753-Q	194L-A16-1753-Q
MODULAR ON-OFF SWITCH 0-1 4P	LA2-16-1754-Q	194L-A16-1754-Q
MODULAR ON-OFF SW. 0-1 6P	LA2-16-1756-Q	194L-A16-1756-Q
MODULAR C/OVER SW. 1-0-2 1P	LA2-16-3251-Q	194L-A16-3251-Q
MODULAR C/OVER SW. 1-0-2 2P	LA2-16-3252-Q	194L-A16-3252-Q
MODULAR C/OVER SW. 1-0-2 3P	LA2-16-3253-Q	194L-A16-3253-Q
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LE2-20-1753-N6	194L-E20-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LE2-20-1754-N6	194L-E20-1754-6N
ON-OFF SWITCH 0-1 1P	LE2-20-1501	194L-E20-1501
ON-OFF SWITCH 0-1 2P	LE2-20-1502	194L-E20-1502
ON-OFF SWITCH 0-1 3P	LE2-20-1503	194L-E20-1503
ON-OFF SWITCH 0-1 4P	LE2-20-1504	194L-E20-1504
ON-OFF SWITCH 0-1 5P	LE2-20-1505	194L-E20-1505
ON-OFF SWITCH 0-1 6P	LE2-20-1506	194L-E20-1506
ON-OFF SWITCH 0-1 1P	LE2-20-1751	194L-E20-1751

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ON-OFF SWITCH 0-1 2P	LE2-20-1752	194L-E20-1752
ON-OFF SWITCH 0-1 3P	LE2-20-1753	194L-E20-1753
ON-OFF SWITCH 0-1 4P	LE2-20-1754	194L-E20-1754
ON-OFF SWITCH 0-1 5P	LE2-20-1755	194L-E20-1755
ON-OFF SWITCH 0-1 6P	LE2-20-1756	194L-E20-1756
ON-OFF SWITCH 0-1 4P(1L)	LE2-20-1764	194L-E20-1764
ON-OFF SWITCH 0-1 5P(3L)	LE2-20-1765	194L-E20-1765
ON-OFF SWITCH 0-1 4P(3L)	LE2-20-1774	194L-E20-1774
ON-OFF SWITCH 0-1 1P	LE2-20-1781	194L-E20-1781
ON-OFF SWITCH 0-1 2P	LE2-20-1782	194L-E20-1782
ON-OFF SWITCH 0-1 3P	LE2-20-1783	194L-E20-1783
ON-OFF SWITCH 0-1 4P	LE2-20-1784	194L-E20-1784
CHANGEOVER 1-2 1P	LE2-20-2251	194L-E20-2251
CHANGEOVER 1-2 2P	LE2-20-2252	194L-E20-2252
CHANGEOVER 1-2 3P	LE2-20-2253	194L-E20-2253
CHANGEOVER 1-2 4P	LE2-20-2254	194L-E20-2254
CHANGEOVER 1-2 5P	LE2-20-2255	194L-E20-2255
CHANGEOVER 1-2 1P	LE2-20-2501	194L-E20-2501
CHANGEOVER 1-2 2P	LE2-20-2502	194L-E20-2502
CHANGEOVER 1-2 3P	LE2-20-2503	194L-E20-2503
CHANGEOVER 1-2 4P	LE2-20-2504	194L-E20-2504
CHANGEOVER 1-2 5P	LE2-20-2505	194L-E20-2505
CHANGEOVER 1-0-2 1P	LE2-20-3001	194L-E20-3001
CHANGEOVER 1-0-2 2P	LE2-20-3002	194L-E20-3002
CHANGEOVER 1-0-2 3P	LE2-20-3003	194L-E20-3003
CHANGEOVER 1-0-2 1P	LE2-20-3251	194L-E20-3251
CHANGEOVER 1-0-2 2P	LE2-20-3252	194L-E20-3252
CHANGEOVER 1-0-2 3P	LE2-20-3253	194L-E20-3253
CHANGEOVER 1-0-2 4P	LE2-20-3254	194L-E20-3254
CHANGEOVER 1>0<2 1P	LE2-20-3261	194L-E20-3261
CHANGEOVER 1>0<2 2P	LE2-20-3262	194L-E20-3262
CHANGEOVER 1>0<2 3P	LE2-20-3263	194L-E20-3263
CHANGEOVER 1-0-2 1P	LE2-20-3501	194L-E20-3501
CHANGEOVER 1-0-2 2P	LE2-20-3502	194L-E20-3502
CHANGEOVER 1-0-2 3P	LE2-20-3503	194L-E20-3503
CHANGEOVER 1-0-2 4P	LE2-20-3504	194L-E20-3504
CHANGEOVER 1-0-2 1P	LE2-20-3751	194L-E20-3751
CHANGEOVER 1-0-2 2P	LE2-20-3752	194L-E20-3752
CHANGEOVER 1-0-2 3P	LE2-20-3753	194L-E20-3753
CHANGEOVER 1-0-2 4P	LE2-20-3754	194L-E20-3754
STEP SWITCH 1-2-3 1P	LE2-20-4251	194L-E20-4251
STEP SWITCH 1-2-3 2P	LE2-20-4252	194L-E20-4252
STEP SWITCH 1-2-3 3P	LE2-20-4253	194L-E20-4253
STEP SWITCH 1-2-3-4 1P	LE2-20-4261	194L-E20-4261
STEP SWITCH 1-2-3-4 2P	LE2-20-4262	194L-E20-4262
STEP SWITCH 1-2-3-4 3P	LE2-20-4263	194L-E20-4263
STEP SWITCH 1-2-3-4-5 1P	LE2-20-4271	194L-E20-4271
STEP SWITCH 1-2-3-4-5-6 1P	LE2-20-4281	194L-E20-4281
STEP SWITCH 1-2-3 1P	LE2-20-4291	194L-E20-4291
STEP SWITCH 1-2-3-4 1P	LE2-20-4301	194L-E20-4301
STEP SWITCH 1-2-3-4 2P	LE2-20-4302	194L-E20-4302
STEP SWITCH 1-2-3-4 3P	LE2-20-4303	194L-E20-4303
STEP SWITCH 1-2-3-4-5-6 1P	LE2-20-4311	194L-E20-4311

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
STEP SWITCH 1-2-3 1P	LE2-20-4501	194L-E20-4501
STEP SWITCH 1-2-3 2P	LE2-20-4502	194L-E20-4502
STEP SWITCH 1-2-3 3P	LE2-20-4503	194L-E20-4503
STEP SWITCH 1-2-3-4 1P	LE2-20-4511	194L-E20-4511
STEP SWITCH 1-2-3-4 2P	LE2-20-4512	194L-E20-4512
STEP SWITCH 1-2-3-4 3P	LE2-20-4513	194L-E20-4513
STEP SWITCH 1-2-3-4-5 1P	LE2-20-4521	194L-E20-4521
STEP SWITCH 1-2-3-4-5-6 1P	LE2-20-4531	194L-E20-4531
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5001	194L-E20-5001
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5002	194L-E20-5002
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5003	194L-E20-5003
STEP SWITCH 0-1-2...5 1P	LE2-20-5011	194L-E20-5011
STEP SWITCH 0-1-2...5 2P	LE2-20-5012	194L-E20-5012
STEP SWITCH 0-1-2...5 3P	LE2-20-5013	194L-E20-5013
STEP SWITCH 0-1-2...6 1P	LE2-20-5021	194L-E20-5021
STEP SWITCH 0-1-2...6 2P	LE2-20-5022	194L-E20-5022
STEP SWITCH 0-1-2 1P	LE2-20-5251	194L-E20-5251
STEP SWITCH 0-1-2 2P	LE2-20-5252	194L-E20-5252
STEP SWITCH 0-1-2 3P	LE2-20-5253	194L-E20-5253
STEP SWITCH 0-1-2-3 1P	LE2-20-5261	194L-E20-5261
STEP SWITCH 0-1-2-3 2P	LE2-20-5262	194L-E20-5262
STEP SWITCH 0-1-2-3 3P	LE2-20-5263	194L-E20-5263
STEP SWITCH 0-1-2-3-4 1P	LE2-20-5271	194L-E20-5271
STEP SWITCH 0-1-2-3-4 2P	LE2-20-5272	194L-E20-5272
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5273	194L-E20-5273
STEP SWITCH 0-1-2...5 1P	LE2-20-5281	194L-E20-5281
STEP SWITCH 0-1-2...5 2P	LE2-20-5282	194L-E20-5282
STEP SWITCH 0-1-2...5 3P	LE2-20-5283	194L-E20-5283
STEP SWITCH 0-1-2...6 1P	LE2-20-5291	194L-E20-5291
STEP SWITCH 0-1-2...6 2P	LE2-20-5292	194L-E20-5292
STEP SWITCH 0-1-2-3 1P	LE2-20-5301	194L-E20-5301
STEP SWITCH 0-1-2-3 2P	LE2-20-5302	194L-E20-5302
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5311	194L-E20-5311
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5312	194L-E20-5312
STEP SWITCH 0-1-2...5 1P	LE2-20-5321	194L-E20-5321
STEP SWITCH 0-1-2...6 1P	LE2-20-5331	194L-E20-5331
STEP SWITCH 0-1-2...7 1P	LE2-20-5341	194L-E20-5341
STEP SWITCH 0-1-2 1P	LE2-20-5501	194L-E20-5501
STEP SWITCH 0-1-2 2P	LE2-20-5502	194L-E20-5502
STEP SWITCH 0-1-2 3P	LE2-20-5503	194L-E20-5503
STEP SWITCH 0-1-2-3 1P	LE2-20-5511	194L-E20-5511
STEP SWITCH 0-1-2-3 2P	LE2-20-5512	194L-E20-5512
STEP SWITCH 0-1-2-3 3P	LE2-20-5513	194L-E20-5513
STEP SWITCH 0-1-2-3-4 1P	LE2-20-5521	194L-E20-5521
STEP SWITCH 0-1-2-3-4 2P	LE2-20-5522	194L-E20-5522
STEP SWITCH 0-1-2-3-4 3P	LE2-20-5523	194L-E20-5523
STEP SWITCH 0-1-2...5 1P	LE2-20-5531	194L-E20-5531
STEP SWITCH 0-1-2...5 2P	LE2-20-5532	194L-E20-5532
STEP SWITCH 0-1-2...5 3P	LE2-20-5533	194L-E20-5533
GROUP SWITCH 0-1-2-3 1P	LE2-20-6001	194L-E20-6001
GROUP SWITCH 0-1-2 1P	LE2-20-6501	194L-E20-6501
GROUP SWITCH 0-1-2-3 1P	LE2-20-6511	194L-E20-6511
REVERSING 1>0<2 3P	LE2-20-7003	194L-E20-7003

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
STAR-DELTA 0-Y-D 3P	LE2-20-7253	194L-E20-7253
STAR-DELTA 0-Y-D 3P	LE2-20-7283	194L-E20-7283
DAHLANDER 1-0-2 3P	LE2-20-7293	194L-E20-7293
REVERSING 1-0-2 3P	LE2-20-7303	194L-E20-7303
REVERSING 1>0<2 3P	LE2-20-7313	194L-E20-7313
STAR-DELTA 0-Y-D 3P	LE2-20-7323	194L-E20-7323
STARTERS 0-M-A 2P	LE2-20-7332	194L-E20-7332
REVERSING A-M-0-M-A 2P	LE2-20-7342	194L-E20-7342
REVERSING 1-0-2 2P	LE2-20-7352	194L-E20-7352
STAR-DELTA 0-Y-D 3P	LE2-20-7503	194L-E20-7503
STAR-DELTA 0-Y-D 3P	LE2-20-7513	194L-E20-7513
DAHLANDER 0-1-2 3P	LE2-20-7523	194L-E20-7523
DAHLANDER 1-0-2 3P	LE2-20-7533	194L-E20-7533
REVERSING 1-0-2 3P	LE2-20-7543	194L-E20-7543
STAR-DELTA 0-Y-D 3P	LE2-20-7553	194L-E20-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-20-8001	194L-E20-8001
VOLTMETER 0-RS-ST-TR	LE2-20-8021	194L-E20-8021
VOLTMETER 0-RN-SN-TN	LE2-20-8031	194L-E20-8031
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-20-8251	194L-E20-8251
VOLTMETER 0-RS-ST-TR-0	LE2-20-8261	194L-E20-8261
VOLTMETER 0-RS-ST-TR	LE2-20-8271	194L-E20-8271
VOLTMETER 0-RN-SN-TN-0	LE2-20-8281	194L-E20-8281
VOLTMETER 0-RN-SN-TN	LE2-20-8291	194L-E20-8291
VOLTMETER 0-RS-ST-TR-0	LE2-20-8302	194L-E20-8302
VOLTMETER 0-RN-SN-TN-0	LE2-20-8312	194L-E20-8312
VOLTMETER 0-RS-.0-R1S1.-.T1R1	LE2-20-8322	194L-E20-8322
VOLTMETER RN-0-RS-ST-TR	LE2-20-8332	194L-E20-8332
AMMETER 0-1-2-3 1P	LE2-20-8751	194L-E20-8751
AMMETER 0-1-2-3 2P	LE2-20-8752	194L-E20-8752
AMMETER 0-1-2-3-4 1P	LE2-20-8761	194L-E20-8761
AMMETER 0-1 1P	LE2-20-8771	194L-E20-8771
ON-OFF SWITCH <START 1P	LE2-20-9001	194L-E20-9001
ON-OFF SWITCH STOP> 1P	LE2-20-9011	194L-E20-9011
ON-OFF SWITCH STOP><START 1P	LE2-20-9021	194L-E20-9021
ON-OFF SWITCH STOP><START 1P	LE2-20-9251	194L-E20-9251
ON-OFF SWITCH 0-1 <START 1P	LE2-20-9751	194L-E20-9751
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LA2-20-1753-N6	194L-A20-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LA2-20-1754-N6	194L-A20-1754-6N
ON-OFF SWITCH 0-1 1P	LA2-20-1501	194L-A20-1501
ON-OFF SWITCH 0-1 2P	LA2-20-1502	194L-A20-1502
ON-OFF SWITCH 0-1 3P	LA2-20-1503	194L-A20-1503
ON-OFF SWITCH 0-1 4P	LA2-20-1504	194L-A20-1504
ON-OFF SWITCH 0-1 5P	LA2-20-1505	194L-A20-1505
ON-OFF SWITCH 0-1 6P	LA2-20-1506	194L-A20-1506
ON-OFF SWITCH 0-1 1P	LA2-20-1751	194L-A20-1751
ON-OFF SWITCH 0-1 2P	LA2-20-1752	194L-A20-1752
ON-OFF SWITCH 0-1 3P	LA2-20-1753	194L-A20-1753
ON-OFF SWITCH 0-1 4P	LA2-20-1754	194L-A20-1754
ON-OFF SWITCH 0-1 5P	LA2-20-1755	194L-A20-1755
ON-OFF SWITCH 0-1 6P	LA2-20-1756	194L-A20-1756
ON-OFF SWITCH 0-1 4P	LA2-20-1764	194L-A20-1764
ON-OFF SWITCH 0-1 5P	LA2-20-1765	194L-A20-1765

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ON-OFF SWITCH 0-1 4P	LA2-20-1774	194L-A20-1774
ON-OFF SWITCH 0-1 1P	LA2-20-1781	194L-A20-1781
ON-OFF SWITCH 0-1 2P	LA2-20-1782	194L-A20-1782
ON-OFF SWITCH 0-1 3P	LA2-20-1783	194L-A20-1783
ON-OFF SWITCH 0-1 4P	LA2-20-1784	194L-A20-1784
CHANGEOVER 1-2 1P	LA2-20-2251	194L-A20-2251
CHANGEOVER 1-2 2P	LA2-20-2252	194L-A20-2252
CHANGEOVER 1-2 3P	LA2-20-2253	194L-A20-2253
CHANGEOVER 1-2 4P	LA2-20-2254	194L-A20-2254
CHANGEOVER 1-0-2 1P	LA2-20-3251	194L-A20-3251
CHANGEOVER 1-0-2 2P	LA2-20-3252	194L-A20-3252
CHANGEOVER 1-0-2 3P	LA2-20-3253	194L-A20-3253
CHANGEOVER 1-0-2 4P	LA2-20-3254	194L-A20-3254
CHANGEOVER 1>0<2 3P	LA2-20-3263	194L-A20-3263
CHANGEOVER 1-0-2 3P	LA2-20-3503	194L-A20-3503
CHANGEOVER 1-0-2 4P	LA2-20-3504	194L-A20-3504
CHANGEOVER 1-0-2 3P	LA2-20-3753	194L-A20-3753
STEP SWITCH 1-2-3 1P	LA2-20-4251	194L-A20-4251
STEP SWITCH 1-2-3-4 1P	LA2-20-4261	194L-A20-4261
STEP SWITCH 1-2-3-4-5 1P	LA2-20-4271	194L-A20-4271
STEP SWITCH 1-2-3-4-5-6 1P	LA2-20-4281	194L-A20-4281
STEP SWITCH 0-1-2-3 1P	LA2-20-5261	194L-A20-5261
STEP SWITCH 0-1-2-3-4 1P	LA2-20-5271	194L-A20-5271
STEP SWITCH 0-1-2-...-5 1P	LA2-20-5281	194L-A20-5281
STEP SWITCH 0-1-2-...-6 1P	LA2-20-5291	194L-A20-5291
STAR-DELTA 0-Y-D 3P	LA2-20-7253	194L-A20-7253
DAHLANDER 1-0-2 3P	LA2-20-7293	194L-A20-7293
REVERSING 1-0-2 3P	LA2-20-7303	194L-A20-7303
REVERSING 1>0<2 3P	LA2-20-7313	194L-A20-7313
STAR-DELTA 0-Y-D 3P	LA2-20-7323	194L-A20-7323
STAR-DELTA 0-Y-D 3P	LA2-20-7553	194L-A20-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LA2-20-8251	194L-A20-8251
VOLTMETER 0-RS-ST-TR-0	LA2-20-8261	194L-A20-8261
VOLTMETER 0-RS-ST-TR	LA2-20-8271	194L-A20-8271
VOLTMETER 0-RN-SN-TN-0	LA2-20-8281	194L-A20-8281
VOLTMETER 0-RN-SN-TN	LA2-20-8291	194L-A20-8291
VOLTMETER 0-RS-ST-TR-0	LA2-20-8302	194L-A20-8302
VOLTMETER 0-RN-SN-TN-0	LA2-20-8312	194L-A20-8312
VOLTMETER 0-RS-...-0-R1S1-...-T1R1	LA2-20-8322	194L-A20-8322
AMMETER 0-1-2-3 1P	LA2-20-8751	194L-A20-8751
AMMETER 1-2-3-4 1P	LA2-20-8761	194L-A20-8761
AMMETER 0-1 1P	LA2-20-8771	194L-A20-8771
ON-OFF SWITCH <START 1P	LA2-20-9001	194L-A20-9001
ON-OFF SWITCH STOP> 1P	LA2-20-9011	194L-A20-9011
ON-OFF SWITCH STOP><START 1P	LA2-20-9021	194L-A20-9021
ON-OFF SWITCH STOP><START 1P	LA2-20-9251	194L-A20-9251
ON-OFF SWITCH 0-1<START 1P	LA2-20-9751	194L-A20-9751
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LE2-25-1753-N6	194L-E25-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LE2-25-1754-N6	194L-E25-1754-6N
ON-OFF SWITCH 0-1 1P	LE2-25-1501	194L-E25-1501
ON-OFF SWITCH 0-1 2P	LE2-25-1502	194L-E25-1502
ON-OFF SWITCH 0-1 3P	LE2-25-1503	194L-E25-1503

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ON-OFF SWITCH 0-1 4P	LE2-25-1504	194L-E25-1504
ON-OFF SWITCH 0-1 5P	LE2-25-1505	194L-E25-1505
ON-OFF SWITCH 0-1 6P	LE2-25-1506	194L-E25-1506
ON-OFF SWITCH 0-1 1P	LE2-25-1751	194L-E25-1751
ON-OFF SWITCH 0-1 2P	LE2-25-1752	194L-E25-1752
ON-OFF SWITCH 0-1 3P	LE2-25-1753	194L-E25-1753
ON-OFF SWITCH 0-1 4P	LE2-25-1754	194L-E25-1754
ON-OFF SWITCH 0-1 5P	LE2-25-1755	194L-E25-1755
ON-OFF SWITCH 0-1 6P	LE2-25-1756	194L-E25-1756
ON-OFF SWITCH 0-1 4P	LE2-25-1764	194L-E25-1764
ON-OFF SWITCH 0-1 5P	LE2-25-1765	194L-E25-1765
ON-OFF SWITCH 0-1 4P	LE2-25-1774	194L-E25-1774
ON-OFF SWITCH 0-1 1P	LE2-25-1781	194L-E25-1781
ON-OFF SWITCH 0-1 2P	LE2-25-1782	194L-E25-1782
ON-OFF SWITCH 0-1 3P	LE2-25-1783	194L-E25-1783
ON-OFF SWITCH 0-1 4P	LE2-25-1784	194L-E25-1784
CHANGEOVER 1-2 1P	LE2-25-2251	194L-E25-2251
CHANGEOVER 1-2 2P	LE2-25-2252	194L-E25-2252
CHANGEOVER 1-2 3P	LE2-25-2253	194L-E25-2253
CHANGEOVER 1-2 4P	LE2-25-2254	194L-E25-2254
CHANGEOVER 1-2 5P	LE2-25-2255	194L-E25-2255
CHANGEOVER 1-2 1P	LE2-25-2501	194L-E25-2501
CHANGEOVER 1-2 2P	LE2-25-2502	194L-E25-2502
CHANGEOVER 1-2 3P	LE2-25-2503	194L-E25-2503
CHANGEOVER 1-2 4P	LE2-25-2504	194L-E25-2504
CHANGEOVER 1-2 5P	LE2-25-2505	194L-E25-2505
CHANGEOVER 1-0-2 1P	LE2-25-3001	194L-E25-3001
CHANGEOVER 1-0-2 2P	LE2-25-3002	194L-E25-3002
CHANGEOVER 1-0-2 3P	LE2-25-3003	194L-E25-3003
CHANGEOVER 1-0-2 1P	LE2-25-3251	194L-E25-3251
CHANGEOVER 1-0-2 2P	LE2-25-3252	194L-E25-3252
CHANGEOVER 1-0-2 3P	LE2-25-3253	194L-E25-3253
CHANGEOVER 1-0-2 4P	LE2-25-3254	194L-E25-3254
CHANGEOVER 1>0<2 1P	LE2-25-3261	194L-E25-3261
CHANGEOVER 1>0<2 2P	LE2-25-3262	194L-E25-3262
CHANGEOVER 1>0<2 3P	LE2-25-3263	194L-E25-3263
CHANGEOVER 1-0-2 1P	LE2-25-3501	194L-E25-3501
CHANGEOVER 1-0-2 2P	LE2-25-3502	194L-E25-3502
CHANGEOVER 1-0-2 3P	LE2-25-3503	194L-E25-3503
CHANGEOVER 1-0-2 4P	LE2-25-3504	194L-E25-3504
CHANGEOVER 1-0-2 1P	LE2-25-3751	194L-E25-3751
CHANGEOVER 1-0-2 2P	LE2-25-3752	194L-E25-3752
CHANGEOVER 1-0-2 3P	LE2-25-3753	194L-E25-3753
CHANGEOVER 1-0-2 4P	LE2-25-3754	194L-E25-3754
STEP SWITCH 1-2-3 1P	LE2-25-4251	194L-E25-4251
STEP SWITCH 1-2-3 2P	LE2-25-4252	194L-E25-4252
STEP SWITCH 1-2-3 3P	LE2-25-4253	194L-E25-4253
STEP SWITCH 1-2-3-4 1P	LE2-25-4261	194L-E25-4261
STEP SWITCH 1-2-3-4 2P	LE2-25-4262	194L-E25-4262
STEP SWITCH 1-2-3-4 3P	LE2-25-4263	194L-E25-4263
STEP SWITCH 1-2-3-4-5 1P	LE2-25-4271	194L-E25-4271
STEP SWITCH 1-2-3-4-5-6 1P	LE2-25-4281	194L-E25-4281
STEP SWITCH 1-2-3 1P	LE2-25-4291	194L-E25-4291

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
STEP SWITCH 1-2-3-4 1P	LE2-25-4301	194L-E25-4301
STEP SWITCH 1-2-3-4 2P	LE2-25-4302	194L-E25-4302
STEP SWITCH 1-2-3-4 3P	LE2-25-4303	194L-E25-4303
STEP SWITCH 1-2-3-4-5-6 1P	LE2-25-4311	194L-E25-4311
STEP SWITCH 1-2-3 1P	LE2-25-4501	194L-E25-4501
STEP SWITCH 1-2-3 2P	LE2-25-4502	194L-E25-4502
STEP SWITCH 1-2-3 3P	LE2-25-4503	194L-E25-4503
STEP SWITCH 1-2-3-4 1P	LE2-25-4511	194L-E25-4511
STEP SWITCH 1-2-3-4 2P	LE2-25-4512	194L-E25-4512
STEP SWITCH 1-2-3-4 3P	LE2-25-4513	194L-E25-4513
STEP SWITCH 1-2-3-4-5 1P	LE2-25-4521	194L-E25-4521
STEP SWITCH 1-2-3-4-5-6 1P	LE2-25-4531	194L-E25-4531
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5001	194L-E25-5001
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5002	194L-E25-5002
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5003	194L-E25-5003
STEP SWITCH 0-1-2...5 1P	LE2-25-5011	194L-E25-5011
STEP SWITCH 0-1-2...5 2P	LE2-25-5012	194L-E25-5012
STEP SWITCH 0-1-2...5 3P	LE2-25-5013	194L-E25-5013
STEP SWITCH 0-1-2...6 1P	LE2-25-5021	194L-E25-5021
STEP SWITCH 0-1-2...6 2P	LE2-25-5022	194L-E25-5022
STEP SWITCH 0-1-2 1P	LE2-25-5251	194L-E25-5251
STEP SWITCH 0-1-2 2P	LE2-25-5252	194L-E25-5252
STEP SWITCH 0-1-2 3P	LE2-25-5253	194L-E25-5253
STEP SWITCH 0-1-2-3 1P	LE2-25-5261	194L-E25-5261
STEP SWITCH 0-1-2-3 2P	LE2-25-5262	194L-E25-5262
STEP SWITCH 0-1-2-3 3P	LE2-25-5263	194L-E25-5263
STEP SWITCH 0-1-2-3-4 1P	LE2-25-5271	194L-E25-5271
STEP SWITCH 0-1-2-3-4 2P	LE2-25-5272	194L-E25-5272
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5273	194L-E25-5273
STEP SWITCH 0-1-2...5 1P	LE2-25-5281	194L-E25-5281
STEP SWITCH 0-1-2...5 2P	LE2-25-5282	194L-E25-5282
STEP SWITCH 0-1-2...5 3P	LE2-25-5283	194L-E25-5283
STEP SWITCH 0-1-2...6 1P	LE2-25-5291	194L-E25-5291
STEP SWITCH 0-1-2...6 2P	LE2-25-5292	194L-E25-5292
STEP SWITCH 0-1-2-3 1P	LE2-25-5301	194L-E25-5301
STEP SWITCH 0-1-2-3 2P	LE2-25-5302	194L-E25-5302
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5311	194L-E25-5311
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5312	194L-E25-5312
STEP SWITCH 0-1-2...5 1P	LE2-25-5321	194L-E25-5321
STEP SWITCH 0-1-2...6 1P	LE2-25-5331	194L-E25-5331
STEP SWITCH 0-1-2...7 1P	LE2-25-5341	194L-E25-5341
STEP SWITCH 0-1-2 1P	LE2-25-5501	194L-E25-5501
STEP SWITCH 0-1-2 2P	LE2-25-5502	194L-E25-5502
STEP SWITCH 0-1-2 3P	LE2-25-5503	194L-E25-5503
STEP SWITCH 0-1-2-3 1P	LE2-25-5511	194L-E25-5511
STEP SWITCH 0-1-2-3 2P	LE2-25-5512	194L-E25-5512
STEP SWITCH 0-1-2-3 3P	LE2-25-5513	194L-E25-5513
STEP SWITCH 0-1-2-3-4 1P	LE2-25-5521	194L-E25-5521
STEP SWITCH 0-1-2-3-4 2P	LE2-25-5522	194L-E25-5522
STEP SWITCH 0-1-2-3-4 3P	LE2-25-5523	194L-E25-5523
STEP SWITCH 0-1-2...5 1P	LE2-25-5531	194L-E25-5531
STEP SWITCH 0-1-2...5 2P	LE2-25-5532	194L-E25-5532
STEP SWITCH 0-1-2...5 3P	LE2-25-5533	194L-E25-5533

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
GROUP SWITCH 0-1-2-3 1P	LE2-25-6001	194L-E25-6001
GROUP SWITCH 0-1-2 1P	LE2-25-6501	194L-E25-6501
GROUP SWITCH 0-1-2-3 1P	LE2-25-6511	194L-E25-6511
REVERSING 1>0<2 3P	LE2-25-7003	194L-E25-7003
STAR-DELTA 0-Y-D 3P	LE2-25-7253	194L-E25-7253
STAR-DELTA D-Y-0-Y-D 3P	LE2-25-7283	194L-E25-7283
DAHLANDER 1-0-2 3P	LE2-25-7293	194L-E25-7293
REVERSING 1-0-2 3P	LE2-25-7303	194L-E25-7303
REVERSING 1>0<2 3P	LE2-25-7313	194L-E25-7313
STAR-DELTA 0-Y-D 3P	LE2-25-7323	194L-E25-7323
STARTERS 0-M-A 2P	LE2-25-7332	194L-E25-7332
REVERSING A-M-0-M-A 2P	LE2-25-7342	194L-E25-7342
REVERSING 1-0-2 2P	LE2-25-7352	194L-E25-7352
STAR-DELTA 0-Y-D 3P	LE2-25-7503	194L-E25-7503
STAR-DELTA D-Y-0-Y-D 3P	LE2-25-7513	194L-E25-7513
DAHLANDER 0-1-2 3P	LE2-25-7523	194L-E25-7523
DAHLANDER 1-0-2 3P	LE2-25-7533	194L-E25-7533
REVERSING 1-0-2 3P	LE2-25-7543	194L-E25-7543
STAR-DELTA 0-Y-D 3P	LE2-25-7553	194L-E25-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-25-8001	194L-E25-8001
VOLTMETER 0-RS-ST-TR	LE2-25-8021	194L-E25-8021
VOLTMETER 0-RN-SN-TN	LE2-25-8031	194L-E25-8031
VOLTMETER TR-ST-RS-0-RN-SN-TN	LE2-25-8251	194L-E25-8251
VOLTMETER 0-RS-ST-TR-0	LE2-25-8261	194L-E25-8261
VOLTMETER 0-RS-ST-TR	LE2-25-8271	194L-E25-8271
VOLTMETER 0-RN-SN-TN-0	LE2-25-8281	194L-E25-8281
VOLTMETER 0-RN-SN-TN	LE2-25-8291	194L-E25-8291
VOLTMETER 0-RS-ST-TR-0	LE2-25-8302	194L-E25-8302
VOLTMETER 0-RN-SN-TN-0	LE2-25-8312	194L-E25-8312
VOLTMETER 0-RS...-0-R1S1...-T1R1	LE2-25-8322	194L-E25-8322
AMMETER 0-1-2-3 1P	LE2-25-8751	194L-E25-8751
AMMETER 0-1-2-3 2P	LE2-25-8752	194L-E25-8752
AMMETER 1-2-3-4 1P	LE2-25-8761	194L-E25-8761
AMMETER 0-1 1P	LE2-25-8771	194L-E25-8771
ON-OFF SWITCH <START 1P	LE2-25-9001	194L-E25-9001
ON-OFF SWITCH STOP> 1P	LE2-25-9011	194L-E25-9011
ON-OFF SWITCH STOP><START 1P	LE2-25-9021	194L-E25-9021
ON-OFF SWITCH STOP><START 1P	LE2-25-9251	194L-E25-9251
ON-OFF SWITCH 0-1<START 1P	LE2-25-9751	194L-E25-9751
MAIN/EMERG. OFF SW. 3P WITH ESC. N	LA2-25-1753-N6	194L-A25-1753-6N
MAIN/EMERG. OFF SW. 4P WITH ESC. N	LA2-25-1754-N6	194L-A25-1754-6N
ON-OFF SWITCH 0-1 1P	LA2-25-1501	194L-A25-1501
ON-OFF SWITCH 0-1 2P	LA2-25-1502	194L-A25-1502
ON-OFF SWITCH 0-1 3P	LA2-25-1503	194L-A25-1503
ON-OFF SWITCH 0-1 4P	LA2-25-1504	194L-A25-1504
ON-OFF SWITCH 0-1 5P	LA2-25-1505	194L-A25-1505
ON-OFF SWITCH 0-1 6P	LA2-25-1506	194L-A25-1506
ON-OFF SWITCH 0-1 1P	LA2-25-1751	194L-A25-1751
ON-OFF SWITCH 0-1 2P	LA2-25-1752	194L-A25-1752
ON-OFF SWITCH 0-1 3P	LA2-25-1753	194L-A25-1753
ON-OFF SWITCH 0-1 4P	LA2-25-1754	194L-A25-1754
ON-OFF SWITCH 0-1 5P	LA2-25-1755	194L-A25-1755

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ON-OFF SWITCH 0-1 6P	LA2-25-1756	194L-A25-1756
ON-OFF SWITCH 0-1 4P	LA2-25-1764	194L-A25-1764
ON-OFF SWITCH 0-1 5P	LA2-25-1765	194L-A25-1765
ON-OFF SWITCH 0-1 4P	LA2-25-1774	194L-A25-1774
ON-OFF SWITCH 0-1 1P	LA2-25-1781	194L-A25-1781
ON-OFF SWITCH 0-1 2P	LA2-25-1782	194L-A25-1782
ON-OFF SWITCH 0-1 3P	LA2-25-1783	194L-A25-1783
ON-OFF SWITCH 0-1 4P	LA2-25-1784	194L-A25-1784
CHANGEOVER 1-2 1P	LA2-25-2251	194L-A25-2251
CHANGEOVER 1-2 2P	LA2-25-2252	194L-A25-2252
CHANGEOVER 1-2 3P	LA2-25-2253	194L-A25-2253
CHANGEOVER 1-2 4P	LA2-25-2254	194L-A25-2254
CHANGEOVER 1-0-2 1P	LA2-25-3251	194L-A25-3251
CHANGEOVER 1-0-2 2P	LA2-25-3252	194L-A25-3252
CHANGEOVER 1-0-2 3P	LA2-25-3253	194L-A25-3253
CHANGEOVER 1-0-2 4P	LA2-25-3254	194L-A25-3254
CHANGEOVER 1>0<2 3P	LA2-25-3263	194L-A25-3263
CHANGEOVER 1-0-2 3P	LA2-25-3503	194L-A25-3503
CHANGEOVER 1-0-2 4P	LA2-25-3504	194L-A25-3504
CHANGEOVER 1-0-2 3P	LA2-25-3753	194L-A25-3753
STEP SWITCH 1-2-3 1P	LA2-25-4251	194L-A25-4251
STEP SWITCH 1-2-3-4 1P	LA2-25-4261	194L-A25-4261
STEP SWITCH 1-2-3-4-5 1P	LA2-25-4271	194L-A25-4271
STEP SWITCH 1-2-3-4-5-6 1P	LA2-25-4281	194L-A25-4281
STEP SWITCH 0-1-2-3 1P	LA2-25-5261	194L-A25-5261
STEP SWITCH 0-1-2-3-4 1P	LA2-25-5271	194L-A25-5271
STEP SWITCH 0-1-2...5 1P	LA2-25-5281	194L-A25-5281
STEP SWITCH 0-1-2...6 1P	LA2-25-5291	194L-A25-5291
STAR-DELTA 0-Y-D 3P	LA2-25-7253	194L-A25-7253
DAHLANDER 1-0-2 3P	LA2-25-7293	194L-A25-7293
REVERSING 1-0-2 3P	LA2-25-7303	194L-A25-7303
REVERSING 1>0<2 3P	LA2-25-7313	194L-A25-7313
STAR-DELTA 0-Y-D 3P	LA2-25-7323	194L-A25-7323
STAR-DELTA 0-Y-D 3P	LA2-25-7553	194L-A25-7553
VOLTMETER TR-ST-RS-0-RN-SN-TN	LA2-25-8251	194L-A25-8251
VOLTMETER 0-RS-ST-TR-0	LA2-25-8261	194L-A25-8261
VOLTMETER 0-RS-ST-TR	LA2-25-8271	194L-A25-8271
VOLTMETER 0-RN-SN-TN-0	LA2-25-8281	194L-A25-8281
VOLTMETER 0-RN-SN-TN	LA2-25-8291	194L-A25-8291
VOLTMETER 0-RS-ST-TR-0	LA2-25-8302	194L-A25-8302
VOLTMETER 0-RN-SN-TN-0	LA2-25-8312	194L-A25-8312
VOLTMETER 0-RS...0-R1S1-.T1R1	LA2-25-8322	194L-A25-8322
AMMETER 0-1-2-3 1P	LA2-25-8751	194L-A25-8751
AMMETER 1-2-3-4 1P	LA2-25-8761	194L-A25-8761
AMMETER 0-1 1P	LA2-25-8771	194L-A25-8771
ON-OFF SWITCH <START 1P	LA2-25-9001	194L-A25-9001
ON-OFF SWITCH STOP> 1P	LA2-25-9011	194L-A25-9011
ON-OFF SWITCH STOP><START 1P	LA2-25-9021	194L-A25-9021
ON-OFF SWITCH STOP><START 1P	LA2-25-9251	194L-A25-9251
ON-OFF SWITCH 0-1>START 1P	LA2-25-9751	194L-A25-9751
LOCKING RING WRENCH	18.104.420-51	194L-N1
STANDARD SHAFT	L2-G 2830	194L-G2830
BLACK 41 MM DIA.KNOB	L2-G 2851N	194L-G2851N

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
BLACK 41 MM DIA.KNOB	L2-G 2854N	194L-G2854N
BLACK KNOB WITH LOCKING FACIL	L2-G 2864N	194L-G2864N
RED KNOB WITH LOCKING FACIL	L2-G 2864R	194L-G2864R
BLACK 31 MM DIA.KNOB	L2-G 2888N	194L-G2888N
RED 31 MM DIA.KNOB	L2-G 2888R	194L-G2888R
STANDARD BLACK KNOB	L2-G 3154N	194L-G3154N
STANDARD RED KNOB	L2-G 3154R	194L-G3154R
STANDARD BLACK KNOB	L2-G 3155N	194L-G3155N
STANDARD RED KNOB	L2-G 3155R	194L-G3155R
RECTANGULAR FRONT FRAME	L2-G 3196	194L-G3196
RECTANGULAR FRONT FRAME	L2-G 3197	194L-G3197
STANDARD SHAFT	L2-G 3380	194L-G3380
TERMINAL COVER 3/4 POLE	LA2-12-C4	194L-A12-C34
TERMINAL COVER 3/4 POLE	LA2-20-C4	194L-A20-C34
SHAFT EXTENSION	LA2-G 2853	194L-G2853
SHAFT	LA2-G 3194	194L-G3194
SHAFT	LA2-G 3195	194L-G3195
METAL. SHAFT EXTENS. 0-1 L=235	LA2-G 3393	194L-G3393
METAL. SHAFT EXTENS. 0-1 L=350	LA2-G 3394	194L-G3394
INSERT FOR METAL. SHAFT EXT.0/ 12H	LA2-G 3398	194L-G3398
INSERT FOR METAL. SHAFT EXT.360	LA2-G 3399	194L-G3399
ENCLOSURE WITH HOLES, H.86,ABS	LA2-G 3572	194L-G3572
ENCLOSURE WITH HOLES,H.111,ABS	LA2-G 3573	194L-G3573
ENCLOSURE WITHOUT HOLES, H.86, ABS	LA2-G 3574	194L-G3574
ENCLOSURE WITHOUT HOLES, H.111, ABS	LA2-G 3575	194L-G3575
ENCLOSURE WITH HOLES, H.86,NORYL	LA2-G 3576	194L-G3576
ENCLOSURE WITH HOLES, H111,NORYL	LA2-G 3577	194L-G3577
ENCL. WITHOUT HOLES, H.86,NORYL	LA2-G 3578	194L-G3578
ENCL. WITHOUT HOLES, H111,NORYL	LA2-G 3579	194L-G3579
TERMINAL COVER 3/4 POLE	LE2-12-C4	194L-E12-C34
TERMINAL COVER 3/4 POLE	LE2-20-C4	194L-E20-C34
ACTUATOR A 48X48 W/O LEG.PLATE	LFC2-A-4-001	194L-HC4A-001
ACTUATOR A 48X48 0-1	LFC2-A-4-150	194L-HC4A-150
ACTUATOR A 48X48 0-1	LFC2-A-4-175	194L-HC4A-175
ACTUATOR A 48X48 OFF-ON	LFC2-A-4-175I	194L-HC4A-175I
ACTUATOR A 48X48 1-2	LFC2-A-4-225	194L-HC4A-225
ACTUATOR A 48X48 1-2	LFC2-A-4-250	194L-HC4A-250
ACTUATOR A 48X48 1-0-2	LFC2-A-4-325	194L-HC4A-325
ACTUATOR A 48X48 1-0-2	LFC2-A-4-350	194L-HC4A-350
ACTUATOR A 48X48 HAND-0-AUTO	LFC2-A-4-350A	194L-HC4A-350A
ACTUATOR A 48X48 1-2-3	LFC2-A-4-450	194L-HC4A-450
ACTUATOR A 48X48 1-2-3-4	LFC2-A-4-451	194L-HC4A-451
ACTUATOR A 48X48 1-2-3-4-5	LFC2-A-4-452	194L-HC4A-452
ACTUATOR A 48X48 1-2-3-4-5-6	LFC2-A-4-453	194L-HC4A-453

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ACTUATOR A 48X48 0-1-2-3-4-5-6	LFC2-A-4-502	194L-HC4A-502
ACTUATOR A 48X48 0-1-2	LFC2-A-4-525	194L-HC4A-525
ACTUATOR A 48X48 0-1-2-3	LFC2-A-4-526	194L-HC4A-526
ACTUATOR A 48X48 0-1-2-3-4	LFC2-A-4-527	194L-HC4A-527
ACTUATOR A 48X48 0-1-2	LFC2-A-4-550	194L-HC4A-550
ACTUATOR A 48X48 0-1-2-3	LFC2-A-4-551	194L-HC4A-551
ACTUATOR A 48X48 0-1-2-3-4	LFC2-A-4-552	194L-HC4A-552
ACTUATOR A 48X48 0-1-2-3-4-5	LFC2-A-4-553	194L-HC4A-553
ACTUATOR A 48X48 0-Y-D	LFC2-A-4-750	194L-HC4A-750
ACTUATOR A 48X48 TR-ST-RS-0-RN	LFC2-A-4-825	194L-HC4A-825
ACTUATOR A 48X48 L3-././L3-N	LFC2-A-4-825A	194L-HC4A-825A
ACTUATOR A 48X48 0-RS-ST-TR	LFC2-A-4-827	194L-HC4A-827
ACTUATOR A 48X48 0/L1-././L3-L1	LFC2-A-4-827A	194L-HC4A-827A
ACTUATOR A 48X48 0-RN-SN-TN-0	LFC2-A-4-828	194L-HC4A-828
ACTUATOR A 48X48 0-RN-SN-TN	LFC2-A-4-829	194L-HC4A-829
ACTUATOR A 48X48 0/././L3-N	LFC2-A-4-829A	194L-HC4A-829A
ACTUATOR A 48X48 0-1-2-3	LFC2-A-4-875	194L-HC4A-875
ACTUATOR B	LFC2-B-001	194L-HCB-001
ACTUATOR CC 48X48 W/O LEG.PL.	LFC2-CC-4-001	194L-HC4CC-001
ACTUATOR CC 48X48 0-1	LFC2-CC-4-150	194L-HC4CC-150
ACTUATOR CC 48X48 0-1	LFC2-CC-4-178	194L-HC4CC-178
ACTUATOR CC 48X48 OFF-0N	LFC2-CC-4-178I	194L-HC4CC-178I
ACTUATOR CC 48X48 1-0-2	LFC2-CC-4-325	194L-HC4CC-325
ACTUATOR CC 48X48 MAN-0-AUT	LFC2-CC-4-325R	194L-HC4CC-325R
ACTUATOR CC 48X48 1-0-2	LFC2-CC-4-350	194L-HC4CC-350
ACTUATOR CC 48X48 1-0-2	LFC2-CC-4-375	194L-HC4CC-375
ACTUAT.CC 48X48 0-1-2-3-4-5-6-7	LFC2-CC-4-534	194L-HC4CC-534
ACTUATOR CC 48X48 STOP-START	LFC2-CC-4-925	194L-HC4CC-925
ACTUATOR CD 48X48 W/O LEG.PL.	LFC2-CD-4-001	194L-HC4CD-001
ACTUATOR CD 48X48 0-1	LFC2-CD-4-175	194L-HC4CD-175
ACTUATOR CD 48X48 OFF-0N	LFC2-CD-4-175I	194L-HC4CD-175I
ACTUATOR CD 48X48 0-1-2	LFC2-CD-4-525	194L-HC4CD-525
ACTUATOR CD 48X48 0-1-2-3	LFC2-CD-4-526	194L-HC4CD-526
ACTUATOR CD 48X48 0-1-2-3-4	LFC2-CD-4-527	194L-HC4CD-527
ACTUATOR CD 48X48 0-1-2-3-4-5	LFC2-CD-4-528	194L-HC4CD-528
ACTUATOR CD 48X48 0-1-2-3-4-5-6	LFC2-CD-4-529	194L-HC4CD-529
ACTUATOR CD 48X48 0-Y-D	LFC2-CD-4-725	194L-HC4CD-725
ACTUATOR CG 48X48 W/O LEG.PL.	LFC2-CG-4-001	194L-HC4CG-001
ACTUATOR CG 48X48 0-1	LFC2-CG-4-175	194L-HC4CG-175
ACTUATOR CG 48X48 OFF-0N	LFC2-CG-4-175I	194L-HC4CG-175I
ACTUATOR CG 48X48 1-0-2	LFC2-CG-4-375	194L-HC4CG-376
ACTUATOR CH 48X48 W/O LEG.PL.	LFC2-CH-4-001	194L-HC4CH-001
ACTUATOR CK 48X48 W/O LEG.PL.	LFC2-CK-4-001	194L-HC4CK-001
ACTUATOR CK 48X48 1-2	LFC2-CK-4-225	194L-HC4CK-225
ACTUATOR CK 48X48 1-0-2	LFC2-CK-4-325	194L-HC4CK-325
ACTUATOR CK 48X48 MAN-0-AUT	LFC2-CK-4-325R	194L-HC4CK-325R
ACTUATOR CK 48X48 1-2-3	LFC2-CK-4-425	194L-HC4CK-425
ACTUATOR CK 48X48 1-2-3-4	LFC2-CK-4-426	194L-HC4CK-426
ACTUATOR CK 48X48 1-2-3-4-5	LFC2-CK-4-427	194L-HC4CK-427
ACTUATOR CK 48X48 1-2-3-4-5-6	LFC2-CK-4-428	194L-HC4CK-428
ACTUATOR DC W/O LEG.PLATE	LFC2-DC-001	194L-HCDC-001
ACTUATOR DD W/O LEG.PLATE	LFC2-DD-001	194L-HCDD-001
ACTUATOR DG W/O LEG.PLATE	LFC2-DG-001	194L-HCDG-001

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ACTUATOR DH W/O LEG.PLATE	LFC2-DH-001	194L-HCDH-001
ACTUATOR DK W/O LEG.PLATE	LFC2-DK-001	194L-HCDK-001
ACTUATOR E 48X48 W/O LEG.PL.	LFC2-E-4-001	194L-HC4E-001
ACTUATOR E 48X48 0-1	LFC2-E-4-175	194L-HC4E-175
ACTUATOR E 48X48 OFF - ON	LFC2-E-4-175I	194L-HC4E-175I
ACTUATOR I 48X48 0-1	LFC2-I-4-175	194L-HC4I-175
ACTUATOR I 48X48 OFF-ON	LFC2-I-4-175I	194L-HC4I-175I
ACTUATOR L 48X48 W/O LEG.PL.	LFC2-L-4-001	194L-HC4L-001
ACTUATOR L 48X48 0-1	LFC2-L-4-175	194L-HC4L-175
ACTUATOR L 48X48 OFF-ON	LFC2-L-4-175I	194L-HC4L-175I
ACTUATOR A 48X48 W/O LEG.PL.	LFS2-A-4-001	194L-HE4A-001
ACTUATOR A 48X48 0-1	LFS2-A-4-175	194L-HE4A-175
ACTUATOR A 48X48 OFF-ON	LFS2-A-4-175I	194L-HE4A-175I
ACTUATOR I 48X48 0-1	LFS2-A-4-178	194L-HE4A-178
ACTUATOR A 48X48 1-2	LFS2-A-4-225	194L-HE4A-225
ACTUATOR A 48X48 1-2	LFS2-A-4-250	194L-HE4A-250
ACTUATOR A 48X48 1-0-2	LFS2-A-4-325	194L-HE4A-325
ACTUATOR A 48X48 1-0-2	LFS2-A-4-350	194L-HE4A-350
ACTUATOR A 48X48 1-0-2	LFS2-A-4-375	194L-HE4A-375
ACTUATOR A 48X48 1-2-3-4	LFS2-A-4-426	194L-HE4A-426
ACTUATOR A 48X48 1-2-3	LFS2-A-4-450	194L-HE4A-450
ACTUATOR A 48X48 1-2-3-4	LFS2-A-4-451	194L-HE4A-451
ACTUATOR A 48X48 1-2-3-4-5	LFS2-A-4-452	194L-HE4A-452
ACTUATOR A 48X48 1-2-3-4-5-6	LFS2-A-4-453	194L-HE4A-453
ACTUATOR A 48X48 0-1-2	LFS2-A-4-525	194L-HE4A-525
ACTUATOR A 48X48 0-1-2-3	LFS2-A-4-526	194L-HE4A-526
ACTUATOR A 48X48 0-1-2-3-4	LFS2-A-4-527	194L-HE4A-527
ACTUATOR A 48X48 0-1-2	LFS2-A-4-550	194L-HE4A-550
ACTUATOR A 48X48 0-1-2-3	LFS2-A-4-551	194L-HE4A-551
ACTUATOR A 48X48 0-1-2-3-4	LFS2-A-4-552	194L-HE4A-552
ACTUATOR A 48X48 0-1-2-3-4-5	LFS2-A-4-553	194L-HE4A-553
ACTUATOR A 48X48 0-Y-D	LFS2-A-4-725	194L-HE4A-725
ACTUATOR A 48X48 0-Y-D	LFS2-A-4-750	194L-HE4A-750
ACTUATOR A 48X48 TR-ST-RS-0-RN-SN-TN	LFS2-A-4-825	194L-HE4A-825
ACTUATOR A 48X48 L3-L1//O//L3-N	LFS2-A-4-825A	194L-HE4A-825A
ACTUATOR A 48X48 0-RS-ST-TR-0	LFS2-A-4-826	194L-HE4A-826
ACTUATOR A 48X48 0-RS-ST-TR	LFS2-A-4-827	194L-HE4A-827
ACTUATOR A 48X48 0/L1-//L3-L1	LFS2-A-4-827A	194L-HE4A-827A
ACTUATOR A 48X48 0-RN-SN-TN-0	LFS2-A-4-828	194L-HE4A-828
ACTUATOR A 48X48 0-RN-SN-TN	LFS2-A-4-829	194L-HE4A-829
ACTUATOR A 48X48 0/L1-/L2-/L3-N	LFS2-A-4-829A	194L-HE4A-829A
ACTUATOR A 48X48 0-1-2-3	LFS2-A-4-875	194L-HE4A-875
ACTUATOR A 48X48 1-2-3-4	LFS2-A-4-876	194L-HE4A-876
ACTUATOR E 48X48 W/O LEG.PL.	LFS2-E-4-001	194L-HE4E-001
ACTUATOR E 48X48 0-1	LFS2-E-4-175	194L-HE4E-175
ACTUATOR E 48X48 0-1	LFS2-E-4-175	194L-HE4E-175
ACTUATOR E 48X48 OFF-ON	LFS2-E-4-175I	194L-HE4E-175I
ACTUATOR I 48X48 W/O LEG.PL.	LFS2-I-4-001	194L-HE4I-001
ACTUATOR I 48X48 0-1	LFS2-I-4-175	194L-HE4I-175
ACTUATOR I 48X48 OFF-ON	LFS2-I-4-175I	194L-HE4I-175I
ACTUATOR L 48X48 W/O LEG.PL.	LFS2-L-4-001	194L-HE4L-001
ACTUATOR L 48X48 0-1	LFS2-L-4-175	194L-HE4L-175
ACTUATOR L 48X48 OFF-ON	LFS2-L-4-175I	194L-HE4L-175I

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ACTUATOR P DIN45 W/O LEG.PL.	LFS2-P-4-001	194L-HE4P-001
ACTUATOR P DIN45 0-1	LFS2-P-4-175	194L-HE4P-175
ACTUATOR P DIN45 OFF-0N	LFS2-P-4-175I	194L-HE4P-175I
ACTUATOR P DIN45 1-2	LFS2-P-4-225	194L-HE4P-225
ACTUATOR P DIN45 1-0-2	LFS2-P-4-325	194L-HE4P-325
ACTUATOR P DIN45 0-RS-ST-TR-0	LFS2-P-4-826	194L-HE4P-826
ACTUATOR S 48X62 W/O LEG.PL.	LFS2-S-4-001	194L-HE4S-001
ACTUATOR S 48X62 0-1	LFS2-S-4-175	194L-HE4S-175
ACTUATOR S 48X62 OFF-0N	LFS2-S-4-175I	194L-HE4S-175I
ACTUATOR S 48X62 1-0-2	LFS2-S-4-325	194L-HE4S-325
ACTUATOR A 64X64 W/O LEG.PL.	LFS2-A-6-001	194L-HE6A-001
ACTUATOR A 64X64 0-1	LFS2-A-6-175	194L-HE6A-175
ACTUATOR A 64X64 OFF-0N	LFS2-A-6-175I	194L-HE6A-175I
ACTUATOR A 64X64 0-1	LFS2-A-6-178	194L-HE6A-178
ACTUATOR A 64X64 1-2	LFS2-A-6-225	194L-HE6A-225
ACTUATOR A 64X64 1-2	LFS2-A-6-250	194L-HE6A-250
ACTUATOR A 64X64 1-0-2	LFS2-A-6-325	194L-HE6A-325
ACTUATOR A 64X64 1-0-2	LFS2-A-6-350	194L-HE6A-350
ACTUATOR A 64X64 1-0-2	LFS2-A-6-375	194L-HE6A-375
ACTUATOR A 64X64 1-2-3-4	LFS2-A-6-426	194L-HE6A-426
ACTUATOR A 64X64 1-2-3	LFS2-A-6-450	194L-HE6A-450
ACTUATOR A 64X64 1-2-3-4	LFS2-A-6-451	194L-HE6A-451
ACTUATOR A 64X64 1-2-3-4-5	LFS2-A-6-452	194L-HE6A-452
ACTUATOR A 64X64 1-2-3-4-5-6	LFS2-A-6-453	194L-HE6A-453
ACTUATOR A 64X64 0-1-2-3	LFS2-A-6-526	194L-HE6A-526
ACTUATOR A 64X64 0-1-2	LFS2-A-6-550	194L-HE6A-550
ACTUATOR A 64X64 0-1-2-3	LFS2-A-6-551	194L-HE6A-551
ACTUATOR A 64X64 0-1-2-3-4	LFS2-A-6-552	194L-HE6A-552
ACTUATOR A 64X64 0-1-2-3-4-5	LFS2-A-6-553	194L-HE6A-553
ACTUATOR A 64X64 0-Y-D	LFS2-A-6-725	194L-HE6A-725
ACTUATOR A 64X64 0-Y-D	LFS2-A-6-750	194L-HE6A-750
ACTUATOR A 64X64 TR-ST-RS-0-RN-SN-TN	LFS2-A-6-825	194L-HE6A-825
ACTUATOR A 64X64 L3-L1/.0/L3-N	LFS2-A-6-825A	194L-HE6A-825A
ACTUATOR A 64X64 0-RS-ST-TR-0	LFS2-A-6-826	194L-HE6A-826
ACTUATOR A 64X64 0-RS-ST-TR	LFS2-A-6-827	194L-HE6A-827
ACTUATOR A 64X64 O/L1-../L3-L1	LFS2-A-6-827A	194L-HE6A-827A
ACTUATOR A 64X64 0-RN-SN-TN-0	LFS2-A-6-828	194L-HE6A-828
ACTUATOR A 64X64 0-RN-SN-TN	LFS2-A-6-829	194L-HE6A-829
ACTUATOR A 64X64 O/L1-/L2-/L3-N	LFS2-A-6-829A	194L-HE6A-829A
ACTUATOR A 64X64 0-1-2-3	LFS2-A-6-875	194L-HE6A-875
ACTUATOR A 64X64 1-2-3-4	LFS2-A-6-876	194L-HE6A-876
ACTUATOR E 64X64 W/O LEG.PL.	LFS2-E-6-001	194L-HE6E-001
ACTUATOR E 64X64 0-1	LFS2-E-6-175	194L-HE6E-175
ACTUATOR E 64X64 OFF-0N	LFS2-E-6-175I	194L-HE6E-175I
ACTUATOR G 67X67 0-1	LFS2-G-6-175	194L-HE6G-175
ACTUATOR G 67X67 OFF-0N	LFS2-G-6-175 I	194L-HE6G-175I
ACTUATOR G 67X67 0-1-START	LFS2-G-6-175 Z	194L-HE6G-175Z
ACTUATOR I 64X64 W/O LEG.PL.	LFS2-I-6-001	194L-HE6I-001
ACTUATOR I 64X64 0-1	LFS2-I-6-175	194L-HE6I-175
ACTUATOR I 64X64 OFF-0N	LFS2-I-6-175I	194L-HE6I-175I
ACTUATOR L 64X64 W/O LEG.PL.	LFS2-L-6-001	194L-HE6L-001
ACTUATOR L 64X64 0-1	LFS2-L-6-175	194L-HE6L-175
ACTUATOR L 64X64 OFF-0N	LFS2-L-6-175I	194L-HE6L-175I

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
ACTUATOR N 67X67 0-1	LFS2-N-6-175	194L-HE6N-175
ACTUATOR N 67X67 OFF-0N	LFS2-N-6-175 I	194L-HE6N-175I
ACTUATOR S 64X78 W/O LEG.PL.	LFS2-S-6-001	194L-HE6S-001
ACTUATOR A 64X78 0-1	LFS2-S-6-175	194L-HE6S-175
ACTUATOR A 64X78 OFF-0N	LFS2-S-6-175I	194L-HE6S-175I
LEGEND PLATE 48X48 NEUTRAL	LL2-A-4-000	194L-A4-000
LEGEND PLATE 48X48 0-1	LL2-A-4-150	194L-A4-150
LEGEND PLATE 48X48 0-1	LL2-A-4-175	194L-A4-175
LEGEND PLATE 48X48 OFF-0N	LL2-A-4-175I	194L-A4-175I
LEGEND PLATE 48X48 0-1	LL2-A-4-178	194L-A4-178
LEGEND PLATE 48X48 OFF-0N	LL2-A-4-178I	194L-A4-178I
LEGEND PLATE 48X48 1-2	LL2-A-4-225	194L-A4-225
LEGEND PLATE 48X48 1-2	LL2-A-4-250	194L-A4-250
LEGEND PLATE 48X48 1-0-2	LL2-A-4-300	194L-A4-300
LEGEND PLATE 48X48 1-0-2	LL2-A-4-325	194L-A4-325
LEGEND PLATE 48X48 MAN-0-AUT	LL2-A-4-325R	194L-A4-325R
LEGEND PLATE 48X48 1-0-2	LL2-A-4-350	194L-A4-350
LEGEND PLATE A 48X48 HAND-0-AUTO	LL2-A-4-350A	194L-A4-350A
LEGEND PLATE A 64X64 HAND-0-AUTO	LL2-A-4-350A	194L-A4-350A
LEGEND PLATE R 48X48 MAN-0-AUTO	LL2-A-4-350R	194L-A4-350R
LEGEND PLATE R 64X64 MAN-0-AUTO	LL2-A-4-350R	194L-A4-350R
LEGEND PLATE 48X48 1-0-2	LL2-A-4-375	194L-A4-375
LEGEND PLATE 48X48 1-2-3	LL2-A-4-425	194L-A4-425
LEGEND PLATE 48X48 1-2-3-4	LL2-A-4-426	194L-A4-426
LEGEND PLATE 48X48 1-2-3-4-5	LL2-A-4-427	194L-A4-427
LEGEND PLATE 48X48 1-2-3-4-5-6	LL2-A-4-428	194L-A4-428
LEGEND PLATE 48X48 1-2-3	LL2-A-4-429	194L-A4-429
LEGEND PLATE 48X48 1-2-3-4	LL2-A-4-430	194L-A4-430
LEGEND PLATE 48X48 1-2-3-4-5-6	LL2-A-4-431	194L-A4-431
LEGEND PLATE 48X48 1-2-3	LL2-A-4-450	194L-A4-450
LEGEND PLATE 48X48 1-2-3-4	LL2-A-4-451	194L-A4-451
LEGEND PLATE 48X48 1-2-3-4-5	LL2-A-4-452	194L-A4-452
LEGEND PLATE 48X48 1-2-3-4-5-6	LL2-A-4-453	194L-A4-453
LEGEND PLATE 48X48 0-1-2-3-4	LL2-A-4-500	194L-A4-500
LEGEND PLATE 48X48 0-1-2-3-4-5	LL2-A-4-501	194L-A4-501
LEGEND PLATE 48X48 0-1-2-3-4-5-6	LL2-A-4-502	194L-A4-502
LEGEND PLATE 48X48 0-1-2	LL2-A-4-525	194L-A4-525
LEGEND PLATE 48X48 0-1-2-3	LL2-A-4-526	194L-A4-526
LEGEND PLATE 48X48 0-1-2-3-4	LL2-A-4-527	194L-A4-527
LEGEND PLATE 48X48 0-1-2-3-4-5	LL2-A-4-528	194L-A4-528
LEGEND PLATE 48X48 0-1-2-3-4-5-6	LL2-A-4-529	194L-A4-529
LEGEND PLATE 48X48 0-1-2-3	LL2-A-4-530	194L-A4-530
LEGEND PLATE 48X48 0-1-2-3-4	LL2-A-4-531	194L-A4-531
LEGEND PLATE 48X48 0-1-2-3-4-5	LL2-A-4-532	194L-A4-532
LEGEND PLATE 48X48 0-1-2-3-4-5-6	LL2-A-4-533	194L-A4-533
LEGEND PLATE 48X48 0-1-2-3-4-5-6-7	LL2-A-4-534	194L-A4-534
LEGEND PLATE 48X48 0-1-2	LL2-A-4-550	194L-A4-550
LEGEND PLATE 48X48 0-1-2-3	LL2-A-4-551	194L-A4-551
LEGEND PLATE 48X48 0-1-2-3-4	LL2-A-4-552	194L-A4-552

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
LEGEND PLATE 48X48 0-1-2-3-4-5	LL2-A-4-553	194L-A4-553
LEGEND PLATE 48X48 0-1-2-3	LL2-A-4-600	194L-A4-600
LEGEND PLATE 48X48 0-Y-D	LL2-A-4-725	194L-A4-725
LEGEND PLATE 48X48 D-Y-0-Y-D	LL2-A-4-728	194L-A4-728
LEGEND PLATE 48X48 0-Y-D	LL2-A-4-732	194L-A4-732
LEGEND PLATE 48X48 0-M-A	LL2-A-4-733	194L-A4-733
LEGEND PLATE 48X48 A-M-0-M-A	LL2-A-4-734	194L-A4-734
LEGEND PLATE 48X48 0-Y-D	LL2-A-4-750	194L-A4-750
LEGEND PLATE 48X48 D-Y-0-Y-D	LL2-A-4-751	194L-A4-751
LEGEND PLATE 48X48 0-1-2	LL2-A-4-752	194L-A4-752
LEGEND PLATE 48X48 Y-0-D	LL2-A-4-755	194L-A4-755
LEGEND PLATE 48X48 TR-ST-RS-0-RN	LL2-A-4-800	194L-A4-800
LEGEND PLATE A/E/S 48X48 L3-L1//0/.	LL2-A-4-800A	194L-A4-800A
LEGEND PLATE 48X48 0-RS-ST-TR	LL2-A-4-802	194L-A4-802
LEGEND PLATE A/E/S 48X48 0/L1-L2/L2	LL2-A-4-802A	194L-A4-802A
LEGEND PLATE 48X48 0-RN-SN-TN	LL2-A-4-803	194L-A4-803
LEGEND PLATE A/E/S 48X48 0/L1-N/L2-N	LL2-A-4-803A	194L-A4-803A
LEGEND PLATE 48X48 TR-...-0-...-TN	LL2-A-4-825	194L-A4-825
LEGEND PLATE A/E/S 48X48 L3-L1//0/.	LL2-A-4-825A	194L-A4-825A
LEGEND PLATE 48X48 0-RS-ST-TR-0	LL2-A-4-826	194L-A4-826
LEGEND PLATE 48X48 0-RS-ST-TR	LL2-A-4-827	194L-A4-827
LEGEND A/E/S 48X48 0/L1-L2/L2..	LL2-A-4-827A	194L-A4-827A
LEGEND PLATE 48X48 0-RN-SN-TN-0	LL2-A-4-828	194L-A4-828
LEGEND PLATE 48X48 0-RN-SN-TN	LL2-A-4-829	194L-A4-829
LEGEND PL. A/E/S 48X48 0/L1-N/L2-N/L3-N	LL2-A-4-829A	194L-A4-829A
LEGEND PLATE 48X48 0-RS-ST-TR-0	LL2-A-4-830	194L-A4-830
LEGEND PLATE 48X48 0-RN-SN-TN-0	LL2-A-4-831	194L-A4-831
LEGEND PLATE 48X48 0-RS-ST-TR-0-.	LL2-A-4-832	194L-A4-832
LEGEND PLATE A/E/S 48X48 0/L1-L2..L3-L1	LL2-A-4-832A	194L-A4-832A
LEGEND PLATE 48X48 RN-0-RS-ST-TR	LL2-A-4-833	194L-A4-833
LEGEND PLATE A/E/S 48X48 L1-N/0/..L3-L1	LL2-A-4-833A	194L-A4-833A
LEGEND PLATE 48X48 0-1-2-3	LL2-A-4-875	194L-A4-875
LEGEND PLATE 48X48 1-2-3-4	LL2-A-4-876	194L-A4-876
LEGEND PLATE 48X48 <START	LL2-A-4-900	194L-A4-900
LEGEND PLATE 48X48 <STOP	LL2-A-4-901	194L-A4-901
LEGEND PLATE 48X48 STOP><START	LL2-A-4-902	194L-A4-902
LEGEND PLATE 48X48 STOP><START	LL2-A-4-925	194L-A4-925
LEGEND PLATE 48X48 0-1 <START	LL2-A-4-975	194L-A4-975
LEGEND PLATE 64X64 NEUTRAL	LL2-A-6-000	194L-A6-000
LEGEND PLATE 64X64 0-1	LL2-A-6-150	194L-A6-150
LEGEND PLATE 64X64 0-1	LL2-A-6-175	194L-A6-175
LEGEND PLATE 64X64 OFF-0N	LL2-A-6-175I	194L-A6-175I

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
LEGEND PLATE 64X64 0-1	LL2-A-6-178	194L-A6-178
LEGEND PLATE 64X64 OFF-ON	LL2-A-6-178I	194L-A6-178I
LEGEND PLATE 64X64 1-2	LL2-A-6-225	194L-A6-225
LEGEND PLATE 64X64 1-2	LL2-A-6-250	194L-A6-250
LEGEND PLATE 64X64 1-0-2	LL2-A-6-300	194L-A6-300
LEGEND PLATE 64X64 1-0-2	LL2-A-6-325	194L-A6-325
LEGEND PLATE 64X64 MAN-0-AUT	LL2-A-6-325R	194L-A6-325R
LEGEND PLATE 64X64 1-0-2	LL2-A-6-350	194L-A6-350
LEGEND PLATE 64X64 1-0-2	LL2-A-6-375	194L-A6-375
LEGEND PLATE 64X64 1-2-3	LL2-A-6-425	194L-A6-425
LEGEND PLATE 64X64 1-2-3-4	LL2-A-6-426	194L-A6-426
LEGEND PLATE 64X64 1-2-3-4-5	LL2-A-6-427	194L-A6-427
LEGEND PLATE 64X64 1-2-3-4-5-6	LL2-A-6-428	194L-A6-428
LEGEND PLATE 64X64 1-2-3	LL2-A-6-429	194L-A6-429
LEGEND PLATE 64X64 1-2-3-4	LL2-A-6-430	194L-A6-430
LEGEND PLATE 64X64 1-2-3-4-5-6	LL2-A-6-431	194L-A6-431
LEGEND PLATE 64X64 1-2-3	LL2-A-6-450	194L-A6-450
LEGEND PLATE 64X64 1-2-3-4	LL2-A-6-451	194L-A6-451
LEGEND PLATE 64X64 1-2-3-4-5	LL2-A-6-452	194L-A6-452
LEGEND PLATE 64X64 1-2-3-4-5-6	LL2-A-6-453	194L-A6-453
LEGEND PLATE 64X64 0-1-2-3-4	LL2-A-6-500	194L-A6-500
LEGEND PLATE 64X64 0-1-2-3-4-5	LL2-A-6-501	194L-A6-501
LEGEND PLATE E 64X64 0-1-2-3-4-5-6	LL2-A-6-502	194L-A6-502
LEGEND PLATE 64X64 0-1-2	LL2-A-6-525	194L-A6-525
LEGEND PLATE 64X64 0-1-2-3	LL2-A-6-526	194L-A6-526
LEGEND PLATE 64X64 0-1-2-3-4	LL2-A-6-527	194L-A6-527
LEGEND PLATE 64X64 0-1-2-3-4-5	LL2-A-6-528	194L-A6-528
LEGEND PLATE 64X64 0-1-2-3-4-5-6	LL2-A-6-529	194L-A6-529
LEGEND PLATE 64X64 0-1-2-3	LL2-A-6-530	194L-A6-530
LEGEND PLATE 64X64 0-1-2-3-4	LL2-A-6-531	194L-A6-531
LEGEND PLATE 64X64 0-1-2-3-4-5	LL2-A-6-532	194L-A6-532
LEGEND PLATE 64X64 0-1-2-3-4-5-6	LL2-A-6-533	194L-A6-533
LEGEND PLAT.64X64 0-1-2-3-4-5-6-7	LL2-A-6-534	194L-A6-534
LEGEND PLATE 64X64 0-1-2	LL2-A-6-550	194L-A6-550
LEGEND PLATE 64X64 0-1-2-3	LL2-A-6-551	194L-A6-551
LEGEND PLATE 64X64 0-1-2-3-4	LL2-A-6-552	194L-A6-552
LEGEND PLATE 64X64 0-1-2-3-4-5	LL2-A-6-553	194L-A6-553
LEGEND PLATE 64X64 0-1-2-3	LL2-A-6-600	194L-A6-600
LEGEND PLATE 64X64 0-Y-D	LL2-A-6-725	194L-A6-725
LEGEND PLATE 64X64 D-Y-0-Y-D	LL2-A-6-728	194L-A6-728
LEGEND PLATE 64X64 0-Y-D	LL2-A-6-732	194L-A6-732
LEGEND PLATE 64X64 0-M-A	LL2-A-6-733	194L-A6-733
LEGEND PLATE 64X64 A-M-0-M-A	LL2-A-6-734	194L-A6-734
LEGEND PLATE 64X64 0-Y-D	LL2-A-6-750	194L-A6-750
LEGEND PLATE 64X64 D-Y-0-Y-D	LL2-A-6-751	194L-A6-751
LEGEND PLATE 64X64 0-1-2	LL2-A-6-752	194L-A6-752
LEGEND PLATE 64X64 Y-0-D	LL2-A-6-755	194L-A6-755
LEGEND PLATE 64X64 TR-ST-RS-0-RN	LL2-A-6-800	194L-A6-800
LEGEND PLATE A/E/S 64X64 L3-L1//0/.	LL2-A-6-800A	194L-A6-800A
LEGEND PLATE 64X64 0-RS-ST-TR	LL2-A-6-802	194L-A6-802

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
LEGEND PLATE A/E/S 64X64 0/L1-L2/L2	LL2-A-6-802A	194L-A6-802A
LEGEND PLATE 64X64 0-RN-SN-TN	LL2-A-6-803	194L-A6-803
LEGEND PLATE A/E/S 64X64 0/L1-N/L2-N	LL2-A-6-803A	194L-A6-803A
LEGEND PLATE 64X64 TR-..-0-..-TN	LL2-A-6-825	194L-A6-825
LEGEND PLATE A/E/S 64X64 L3-L1/./0/.	LL2-A-6-825A	194L-A6-825A
LEGEND PLATE 64X64 0-RS-ST-TR-0	LL2-A-6-826	194L-A6-826
LEGEND PLATE 64X64 0-RS-ST-TR	LL2-A-6-827	194L-A6-827
LEGEND PLATE A/E/S 64X64 0/L1-L2/L2..	LL2-A-6-827A	194L-A6-827A
LEGEND PLATE 64X64 0-RN-SN-TN-0	LL2-A-6-828	194L-A6-828
LEGEND PLATE 64X64 0-RN-SN-TN	LL2-A-6-829	194L-A6-829
LEGEND PL. A/E/S 64X64 0/L1-N/L2-N/L3-N	LL2-A-6-829A	194L-A6-829A
LEGEND PLATE 64X64 0-RS-ST-TR-0	LL2-A-6-830	194L-A6-830
LEGEND PLATE 64X64 0-RN-SN-TN-0	LL2-A-6-831	194L-A6-831
LEGEND PLATE 64X64 0-RS-ST-TR-0	LL2-A-6-832	194L-A6-832
LEGEND PLATE A/E/S 64X64 0/L1-L2..L3-L1	LL2-A-6-832A	194L-A6-832A
LEGEND PLATE 64X64 RN-0-RS-ST-TR	LL2-A-6-833	194L-A6-833
LEGEND PLATE A/E/S 64X64 L1-N/0/..L3-L1	LL2-A-6-833A	194L-A6-833A
LEGEND PLATE 64X64 0-1-2-3	LL2-A-6-875	194L-A6-875
LEGEND PLATE 64X64 1-2-3-4	LL2-A-6-876	194L-A6-876
LEGEND PLATE 64X64 <START	LL2-A-6-900	194L-A6-900
LEGEND PLATE 64X64 <STOP S	LL2-A-6-901	194L-A6-901
LEGEND PLATE 64X64 STOP><START S	LL2-A-6-902	194L-A6-902
LEGEND PLATE 64X64 STOP><START	LL2-A-6-925	194L-A6-925
LEGEND PLATE 64X64 0-1<START	LL2-A-6-975	194L-A6-975
LEGEND PLATE 48X48 NEUTRAL	LL2-I-4-000	194L-I4-000
LEGEND PLATE 48X48 0-1	LL2-I-4-175	194L-I4-175
LEGEND PLATE 48X48 OFF-0N	LL2-I-4-175I	194L-I4-175I
LEGEND PLATE 48X48 0-1	LL2-I-4-178	194L-I4-178
LEGEND PLATE 48X48 OFF-0N	LL2-I-4-178I	194L-I4-178I
LEGEND PLATE 64X64 NEUTRAL	LL2-I-6-000	194L-I6-000
LEGEND PLATE 64X64 0-1	LL2-I-6-175	194L-I6-175
LEGEND PLATE 64X64 OFF-0N	LL2-I-6-175I	194L-I6-175I
LEGEND PLATE 64X64 0-1	LL2-I-6-178	194L-I6-178
LEGEND PLATE 64X64 OFF-0N	LL2-I-6-178I	194L-I6-178I
LEGEND PLATE 45X54 NEUTRAL	LL2-P-4-000	194L-P4-000
LEGEND PLATE 45X54 0-1	LL2-P-4-178	194L-P4-175
LEGEND PLATE 45X54 OFF-0N	LL2-P-4-175I	194L-P4-175I
LEGEND PLATE 45X54 0-1	LL2-P-4-178	194L-P4-178
LEGEND PLATE 45X54 OFF-0N	LL2-P-4-178I	194L-P4-178I
LEGEND PLATE 45X54 1-2	LL2-P-4-225	194L-P4-225
LEGEND PLATE 45X54 1-0-2	LL2-P-4-325	194L-P4-325
LEGEND PLATE 45X54 MAN-0-AUT	LL2-P-4-325R	194L-P4-325R
LEGEND PLATE 45X54 0-1-2-3	LL2-P-4-530	194L-P4-530

Description	Cat. No. Sprecher+Schuh L2	Cat. No. Allen-Bradley Bulletin 194L
LEGEND PLATE 45X54 TR-..-0-..-TN	LL2-P-4-825	194L-P4-825
LEGEND PLATE P 45X54 L3-L1./0./L3	LL2-P-4-825A	194L-P4-825A
LEGEND PLATE 45X54 0-RS-ST-TR-0	LL2-P-4-826	194L-P4-826
LEGEND PLATE P 45X54 0/L1-L2/L2-L3/..	LL2-P-4-827A	194L-P4-827A
LEGEND PLATE P 45X54 0/L1-N/L2-N/L3-N	LL2-P-4-829A	194L-P4-829A
LEGEND PLATE 45X54 0-RN-SN-TN-0	LL2-P-4-831	194L-P4-831
LEGEND PLATE P 45X54 0/L1-L2..L3-L1	LL2-P-4-832A	194L-P4-832A
LEGEND PLATE P 45X54 L1-N/0./L3-L1	LL2-P-4-833A	194L-P4-833A
LEGEND PLATE 45X54 0-1-2-3	LL2-P-4-875	194L-P4-875



Rockwell Automation helps its customers receive a superior return on their investment by bringing together leading brands in industrial automation, creating a broad spectrum of easy-to-integrate products. These are supported by local technical resources available worldwide, a global network of system solutions providers, and the advanced technology resources of Rockwell.

Worldwide representation.



Argentina • Australia • Austria • Bahrain • Belgium • Bolivia • Brazil • Bulgaria • Canada • Chile • China, People's Republic of • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Dominican Republic • Ecuador • Egypt • El Salvador • Finland • France • Germany • Ghana • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Iran • Ireland • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Macau • Malaysia • Malta • Mexico • Morocco • The Netherlands • New Zealand • Nigeria • Norway • Oman • Pakistan • Panama • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic of • Spain • Sweden • Switzerland • Taiwan • Thailand • Trinidad • Tunisia • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela

Rockwell Automation Headquarters, 1201 South Second Street, Milwaukee, WI 53204 USA, Tel: (1) 414 382-2000, Fax: (1) 414 382-4444

Rockwell Automation European Headquarters SA/NV, avenue Hermann Debrouxlaan, 46, 1160 Brussels, Belgium, Tel: (32) 2 663 06 00, Fax: (32) 2 663 06 40

Rockwell Automation Asia Pacific Headquarters, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846