



THE CIRCUIT IS TYPICAL OF A 16 AMP BUL 2407 FVR STARTER WITH 120 VOLT SEPARATE CONTROL OPTIONS:

- 1 CONTROL CIRCUIT FUSE
- 2 N.O. AUXILIARY CONTACTS ON EACH STARTER
- 2 N.C. AUXILIARY CONTACTS ON EACH STARTER
- 1 N.O. AUXILIARY CONTACT ON THE CIRCUIT BREAKER

A COMPLETE AND ACCURATE REPRESENTATION OF THE CIRCUIT DEPENDS ON THE SIZE AND OPTIONS ORDERED.

**NOTES**

- ① REMOTE DEVICE
- ② DO NOT USE AUTOMATIC RESET MODE IN APPLICATIONS WHERE UNEXPECTED AUTOMATIC RESTART OF THE MOTOR CAN CAUSE INJURY TO PERSONS OR DAMAGE TO EQUIPMENT.
- ☒ THIS IS AN EXTERNAL CIRCUIT BREAKER AUXILIARY AND SHOULD NOT BE USED FOR BREAKER TRIP INDICATION.

References		BUL. 2407 16 AMP		
Revision		TYPE B		
Release	Dimensions Apply Before Surface Treatment			
1 08/28/01	Tolerances Unless Otherwise Specified			
	2 Place Decimal ± .02	Dr.	Date	Sheet 1 Of 1
	3 Place Decimal ± .005	Chkd.	Date	Dwg Size C
Refer. Book	Angles ± 1	Appd.	Date	2407WB005