



RediPANEL Keypad Module Series F

(Bulletin 2705-K11C1 Family)

Introduction

This release note supports the introduction of Series F of the RediPANEL Keypad Module (Bulletin 2705-K11C1 family) which features an improved mounting system. The new system replaces a mounting bracket arrangement with studs and nuts.

Mechanical Installation

This procedure replaces the Mechanical Installation procedure which appears in Publication 2705-ND002.

To install the module, follow the steps outlined below. Throughout installation, refer to the accompanying mounting template (part number 40061-324-01) for exact dimensions.

1. Cut an opening in the panel approximately 5.86 in. (149 mm) H x 8.61 in. (219 mm) W.
2. Drill six 0.250 in. (6.4 mm) diameter holes for the top and bottom mounting studs in the positions indicated on the template.
3. Slide the module through the opening. The mounting tabs will help seat the module tightly against 0.062 in. (1.6 mm) to 0.125 in. (3.2 mm) thick enclosure.

Note: After you slide the module into the enclosure, the built-in mounting tabs secure the module to the enclosure.

4. Install the mounting hardware and tighten to 8 lbs-in. (0.908 N•m).

Allen-Bradley Spares

RediPANEL is a trademark of Allen-Bradley Company, Inc.



Rockwell Automation helps its customers receive a superior return on their investment by bringing together leading brands in industrial automation, creating a broad spectrum of easy-to-integrate products. These are supported by local technical resources available worldwide, a global network of system solutions providers, and the advanced technology resources of Rockwell.

Worldwide representation.



Argentina • Australia • Austria • Bahrain • Belgium • Bolivia • Brazil • Bulgaria • Canada • Chile • China, People's Republic of • Colombia • Costa Rica • Croatia • Cyprus • Czech Republic • Denmark • Dominican Republic • Ecuador • Egypt • El Salvador • Finland • France • Germany • Ghana • Greece • Guatemala • Honduras • Hong Kong • Hungary • Iceland • India • Indonesia • Iran • Ireland • Israel • Italy • Jamaica • Japan • Jordan • Korea • Kuwait • Lebanon • Macau • Malaysia • Malta • Mexico • Morocco • The Netherlands • New Zealand • Nigeria • Norway • Oman • Pakistan • Panama • Peru • Philippines • Poland • Portugal • Puerto Rico • Qatar • Romania • Russia • Saudi Arabia • Singapore • Slovakia • Slovenia • South Africa, Republic of • Spain • Sweden • Switzerland • Taiwan • Thailand • Trinidad • Tunisia • Turkey • United Arab Emirates • United Kingdom • United States • Uruguay • Venezuela

Rockwell Automation Headquarters, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414 382-2000 Fax: (1) 414 382-4444

Rockwell Automation European Headquarters, Avenue Hermann Debroux, 46, 1160 Brussels, Belgium, Tel: (32) 2 663 06 00, Fax: (32) 2 663 06 40

Rockwell Automation Asia Pacific Headquarters, 27/F Citicorp Centre, 18 Whitfield Road, Causeway Bay, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

World Wide Web: <http://www.ab.com>