

# 1756 GuardLogix Controllers

Cat. No. 1756-L61S, 1756-L62S, 1756-L63S, 1756-LSP, 1756-L71S, 1756-L72S, 1756-L73S, 1756-L7SP, 1756-L73SXT, 1756-L7SPXT

## Original Instructions

The GuardLogix® controller is a programmable automation controller with integrated safety for use in functional safety applications up to and including Safety Integrity Level (SIL) 3 and Performance Level (e). The GuardLogix controller is made up of a primary controller and a safety partner that function together in a 1oo2 architecture.



### ATTENTION:

- Before installing, configuring, operating or maintaining this product, read this document and the documents listed in the Additional Resources section for installing, configuring, or operating equipment. Users should familiarize themselves with installation and wiring instructions in addition to requirements of all applicable codes, laws, and standards.
- Installation, adjustments, putting into service, use, assembly, disassembly, and maintenance shall be carried out by suitably trained personnel in accordance with applicable code of practice. In case of malfunction or damage, no attempts at repair should be made. The module should be returned to the manufacturer for repair. Do not dismantle the module.
- If this equipment is used in a manner not specified by the manufacturer, the protection provided by the equipment may be impaired.
- Equipment designated as 'XT' is certified for use only within a surrounding air temperature range of -25...70 °C (-13...158 °F). Equipment designated as 'LXT' is certified for use only within a surrounding air temperature range of -25...60 °C (-13...140 °F) even when used with other 'XT' equipment. Non-XT equipment is certified for use only within a surrounding air temperature range of 0...60 °C (32...140 °F). The equipment must not be used outside of its range.
- Solid state equipment has operational characteristics differing from those of electromechanical equipment. Safety Guidelines for the Application, Installation and Maintenance of Solid State Controls, publication [SGL-1.1](#), available from your local Rockwell Automation sales office or online at <http://www.rockwellautomation.com/literature> describes some important differences between solid state equipment and hard-wired electromechanical devices.

## North American Hazardous Location Approval

The following information applies when operating this equipment in hazardous locations: Products marked "CL I, DIV 2, GP A, B, C, D" are suitable for use in Class I Division 2 Groups A, B, C, D, Hazardous Locations and nonhazardous locations only. Each product is supplied with markings on the rating nameplate indicating the hazardous location temperature code. When combining products within a system, the most adverse temperature code (lowest "T" number) may be used to help determine the overall temperature code of the system. Combinations of equipment in your system are subject to investigation by the local authority having jurisdiction at the time of installation.



### WARNING: EXPLOSION HAZARD

- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.
- Do not disconnect connections to this equipment unless power has been removed or the area is known to be nonhazardous. Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
- Substitution of components may impair suitability for Class I, Division 2.
- If this product contains batteries, they must be changed only in an area known to be nonhazardous.

Informations sur l'utilisation de cet équipement en environnements dangereux:

Les produits marqués "CL I, DIV 2, GP A, B, C, D" ne conviennent qu'à une utilisation en environnements de Classe I Division 2 Groupes A, B, C, D dangereux et non dangereux. Chaque produit est livré avec des marquages sur sa plaque d'identification qui indiquent le code de température pour les environnements dangereux. Lorsque plusieurs produits sont combinés dans un système, le code de température le plus défavorable (code de température le plus faible) peut être utilisé pour déterminer le code de température global du système. Les combinaisons d'équipements dans le système sont sujettes à inspection par les autorités locales qualifiées au moment de l'installation.



### AVERTISSEMENT: RISQUE D'EXPLOSION

- Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher l'équipement.
- Couper le courant ou s'assurer que l'environnement est classé non dangereux avant de débrancher les connecteurs. Fixer tous les connecteurs externes reliés à cet équipement à l'aide de vis, loquets coulissants, connecteurs filetés ou autres moyens fournis avec ce produit.
- La substitution de composants peut rendre cet équipement inadapté à une utilisation en environnement de Classe I, Division 2.
- S'assurer que l'environnement est classé non dangereux avant de changer les piles.

**IMPORTANT** Any illustrations, charts, sample programs, and layout examples shown in this publication are intended solely for the purposes of example. Since there are many variables and requirements associated with any particular installation, Rockwell Automation does not assume responsibility or liability for actual use based upon the examples shown in this publication.



**ATTENTION:** Do not install, configure, operate or maintain this product until you have read the product documentation and the documents in the Additional Resources section for installing, configuring, operating or maintaining equipment. To get the product documentation go to <http://www.rockwellautomation.com/literature/> or contact your local sales office or Rockwell Automation representative.

**ATTENTION:** Ne pas installer, configurer, exploiter ou maintenir ce produit tant que vous n'avez pas lu sa documentation et les documents de la rubrique Documents connexes pour l'installation, la configuration, l'exploitation et la maintenance de l'équipement. Pour obtenir de la documentation, rendez-vous sur le site <http://www.rockwellautomation.com/literature/> ou contactez votre agence commerciale Rockwell Automation locale ou son représentant.

**ACHTUNG:** Für die Installation, Konfiguration, den Betrieb und die Wartung dieses Produkt lesen Sie sich bitte zunächst die Produktdokumentation sowie die Dokumente im Abschnitt „Weitere Informationen“ durch. Die entsprechende Produktdokumentation finden Sie unter <http://www.rockwellautomation.com/literature/> oder kontaktieren Sie Ihr lokales Vertriebsbüro bzw. einen Rockwell Automation-Mitarbeiter.

**ATENCIÓN:** No instale, configure, opere ni mantenga este producto hasta que haya leído la documentación del producto y los documentos en la sección Recursos adicionales para la instalación, configuración, operación o mantenimiento de equipo. Para conseguir la documentación, diríjase a <http://www.rockwellautomation.com/literature/> o póngase en contacto con su oficina regional de ventas o representante de Rockwell Automation.

**ATENÇÃO:** Não instale, configure, opere ou mantenha este produto até que você leia a documentação do produto e os documentos na seção Recursos adicionais para a instalação, configuração, operação ou manutenção do equipamento. Para conseguir a documentação, visite <http://www.rockwellautomation.com/literature/> ou entre em contato com seu escritório de vendas regional ou representante da Rockwell Automation.

**ATTENZIONE:** Non installare, configurare, attivare o riparare questo prodotto senza avere prima letto la relativa documentazione nonché i documenti indicati nella sezione Ulteriori Risorse riguardanti l'installazione, la configurazione, l'attivazione o la riparazione dell'apparecchiatura. Per la documentazione sul prodotto visitare il sito <http://www.rockwellautomation.com/literature/> o contattare l'ufficio vendite o il rappresentante Rockwell Automation di zona.

**注意:** 製品の資料および追加資料に記載の装置の取付け、構成、操作、または保守に関する資料をお読みになるまでは、この製品の取付け、構成、操作、または保守を行なわないでください。製品の資料を入手するには、Web サイト: <http://www.rockwellautomation.com/literature/> にアクセスするか、またはロックウェル・オートメーションの営業または販売代理店までご連絡ください。

**주의사항:** 제품 매뉴얼 혹은 설치, 구성, 가동, 유지와 관련된 추가 지침서를 완전히 숙지하기 전까지 본 제품을 설치 혹은 가동하지 마십시오. 본 제품과 관련된 매뉴얼 혹은 문서를 원하시면 사이트 <http://www.rockwellautomation.com/literature/> 를 방문 해주시거나 해당 지역의 로컬 오토메이선대리점으로 문의하십시오.

**注意:** 若未阅读产品文档以及“其它资源”小节中提及的有关安装、配置、运行或维护设备的相关文档, 请勿安装、配置、运行或维护本产品。请访问 <http://www.rockwellautomation.com/literature/> 或联系您当地的销售办事处或罗克韦尔自动化代表, 以获取产品文档。

**注意:** 在您完整閱讀本產品相關文件及其他關於安裝、配置、操作或維護設備等資料之前, 請勿安裝、配置、操作或維護此產品。您可到下列網站下載所有產品相關文件 <http://www.rockwellautomation.com/literature/>, 或聯繫洛克威爾自動化當地辦公室。

**ВНИМАНИЕ:** Не устанавливайте, не конфигурируйте, не запускайте в эксплуатацию и не поддерживайте работу продукта до прочтения технической документации по продукту и документации в разделе Дополнительные материалы для инсталлирования, конфигурирования, запуска в эксплуатацию и поддержки работы продукта. Чтобы ознакомиться с документацией по продукту, перейдите по ссылке <http://www.rockwellautomation.com/literature/> или свяжитесь с локальным офисом продаж или представителем Rockwell Automation.

**UWAGA:** Nie instaluj i nie uruchamiaj tego urządzenia dopóki nie zapoznasz się z instrukcją użytkownika produktu. Aby uzyskać dokumentację produktu przejdź do strony internetowej <http://www.rockwellautomation.com/literature/> lub skontaktuj się z lokalnym biurem sprzedaży lub przedstawicielstwem firmy Rockwell Automation.

**UPOZORNĚNÍ:** Neprovádějte instalaci, konfiguraci, provoz ani údržbu, pokud jste dosud nepřečetli dokumentaci k produktu a dokumenty obsažené v sekci Doplnující informace pro instalaci, konfiguraci, provoz a údržbu. Tuto dokumentaci můžete získat na <http://www.rockwellautomation.com/literature/> nebo od obchodního zástupce společnosti Rockwell Automation.

**WAARSCHUWING:** Installeer, configureer of onderhoud dit product niet vooraleer u de productdocumentatie en de documenten in de aanvullende informatiesectie voor installatie, werking en onderhoud gelezen hebt. Voor de productinformatie, ga naar <http://www.rockwellautomation.com/literature/> of contacteer uw lokaal Rockwell Automation-kantoor.

# Spare Allen-Bradley Parts

## European Hazardous Location Approval

The following applies to products marked  II 3 G. Such modules:

- Are Equipment Group II, Equipment Category 3, and comply with the Essential Health and Safety Requirements relating to the design and construction of such equipment given in Annex II to Directive 94/9/EC. See the EC Declaration of Conformity at <http://www.rockwellautomation.com/products/certification> for details. The type of protection used is "Ex nA IIC T- or Ex nC IIC T-" according to EN 60079-15. The specific temperature code is marked on the product.
- Are intended for use in areas in which explosive atmospheres caused by gases, vapors, mists, or air or dust mixtures are unlikely to occur, or are likely to occur only infrequently and for short periods. Such locations correspond to Zone 2 classification according to ATEX directive 1999/92/EC.



### WARNING: Special Conditions for Safe Use:

- This equipment shall be mounted in an ATEX certified enclosure with a minimum ingress protection rating of at least IP54 (as defined in IEC60529) and used in an environment of not more than Pollution Degree 2 (as defined in IEC 60664-1) when applied in Zone 2 environments. The enclosure must utilize a tool-removable cover or door.
- This equipment shall be used within its specified ratings defined by Rockwell Automation.
- Provision shall be made to prevent the rated voltage from being exceeded by transient disturbances of more than 140% of the rated voltage when applied in Zone 2 environments.
- This equipment must be used only with ATEX certified Rockwell Automation backplanes.
- Secure any external connections that mate to this equipment by using screws, sliding latches, threaded connectors, or other means provided with this product.
- Do not disconnect equipment unless power has been removed or the area is known to be nonhazardous.

## Environment and Enclosure



This equipment is intended for use in a Pollution Degree 2 industrial environment, in overvoltage Category II applications (as defined in IEC 60664-1), at altitudes up to 2000 m (6562 ft) without derating.

This equipment is not intended for use in residential environments and may not provide adequate protection to radio communication services in such environments.

This equipment is supplied as open-type equipment. It must be mounted within an enclosure that is suitably designed for those specific environmental conditions that will be present and appropriately designed to prevent personal injury resulting from accessibility to live parts. The enclosure must have suitable flame-retardant properties to prevent or minimize the spread of flame, complying with a flame spread rating of 5VA or be approved for the application if non-metallic. The interior of the enclosure must be accessible only by the use of a tool. Subsequent sections of this publication may contain additional information regarding specific enclosure type ratings that are required to comply with certain product safety certifications.

In addition to this publication, see the following:

- Industrial Automation Wiring and Grounding Guidelines, publication [1770-4.1](#), for additional installation requirements
- NEMA 250 and IEC 60529, as applicable, for explanations of the degrees of protection provided by different types of enclosure

## Additional Resources

To view or download product publications, go to <http://www.rockwellautomation.com/literature>. To order paper copies of technical documentation, contact your local Allen-Bradley distributor or Rockwell Automation sales representative.

Resource	Description
GuardLogix 5570 Controllers User Manual, publication <a href="#">1756-UM022</a>	Provides information on how to install, configure, program, and use GuardLogix 5570 controllers in Studio 5000™ Logix Designer projects.
GuardLogix 5570 Controller Systems Safety Reference Manual, publication <a href="#">1756-RM099</a>	Provides information on safety application requirements for GuardLogix 5570 controllers in Studio 5000 Logix Designer projects.
GuardLogix Controllers User Manual, publication <a href="#">1756-UM020</a>	Provides information on how to install, configure, program, and use GuardLogix 5560 and 5570 controllers in RSLogix 5000 projects.
GuardLogix Controller Systems Safety Reference Manual, publication <a href="#">1756-RM093</a>	Provides information on safety application requirements for GuardLogix 5560 and 5570 controllers in RSLogix 5000 projects.
Guidelines for Handling Lithium Batteries Technical Data, publication <a href="#">AG-5.4</a>	Provides guidelines for storing, handling, installing, and disposing of lithium batteries.
Industrial Automation Wiring and Grounding Guidelines, publication <a href="#">1770-4.1</a>	Provides general guidelines for installing a Rockwell Automation industrial system.
Product Certification website, <a href="http://www.rockwellautomation.com/products/certification">http://www.rockwellautomation.com/products/certification</a>	Provides current Declarations of Conformity, Certificates, and full certification details.

Allen-Bradley, GuardLogix, Rockwell Software, Studio 5000, RSLogix, and Rockwell Automation are trademarks of Rockwell Automation, Inc. Trademarks not belonging to Rockwell Automation are property of their respective companies.

Rockwell Otomasyon Ticaret A.Ş., Kar Plaza İş Merkezi E Blok Kat:6 34752 İçerenköy, İstanbul, Tel: +90 (216) 5698400

[www.rockwellautomation.com](http://www.rockwellautomation.com)

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 1756-PC006C-EN-P - December 2012

Supersedes Publication 1756-PC006B-EN-P - July 2012

## Battery Removal



This product may contain a lithium battery that needs to be replaced during the life of the product. For instructions on the removal and replacement of the battery, see the GuardLogix Controllers User Manual, publication [1756-UM020](#). At the end of its life, the battery contained in this product should be collected separately from any unsorted municipal waste. The collection and recycling of batteries helps protect the environment and contributes to the conservation of natural resources as valuable materials are recovered.

## Energy Storage Module

This product may contain an energy storage module (ESM).



WARNING: If your application requires an ESM to deplete its residual stored energy to 40 µJ or less before you transport it into or out of the application, use only the 1756-ESMNSE(XT) module for the primary controller and the 1756-SPESMNSE(XT) for the safety partner. In this case, complete these steps before you remove the ESM:

1. Turn off power to the chassis.

After you turn off power to the chassis, the controller's OK status indicator transitions from Green to Solid Red to OFF.

2. Wait at least 20 minutes for the residual stored energy to decrease to 40 µJ or less before you remove the ESM.

There is no visual indication of when the 20 minutes has expired. You must track that time period.

## Functional Safety

When marked, the controllers are certified by TÜV Rheinland for Functional Safety: capable of SIL 3, according to IEC 61508, and PL e/Cat. 4 according to ISO 13849-1.

## Machinery Directive

The controllers are in conformity with the essential requirements of the Machinery Directive (2006/42/EC) when installed in accordance with the instructions contained in the product documentation. The standards, and technical specifications referred to below have been applied as indicated.

### Standard/Technical Specification

EN 60204-1:2006/A1:2009	Safety of machinery - Electrical equipment of machines - Part 1: General requirements
EN ISO 13849-1:2008/AC:2009	Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design
EN 62061:2005	Safety of machinery - Functional Safety of safety-related electrical, electronic and programmable electronic control systems

PN-184604

Copyright © 2012 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.