



# PowerFlex 700L Active Converter Firmware v3.002

This release note describes major revision 3, minor revision 2 of firmware for PowerFlex 700L Active Converters.

## Introduction

The following information is included in this document:

For information about:	See page:
<a href="#">Determining Firmware Revision Level</a>	<a href="#">1</a>
<a href="#">Firmware Upgrades</a>	<a href="#">1</a>
<a href="#">Enhancements</a>	<a href="#">2</a>
<a href="#">Corrected Anomalies</a>	<a href="#">2</a>
<a href="#">Known Anomalies</a>	<a href="#">2</a>
<a href="#">Restrictions</a>	<a href="#">2</a>
<a href="#">Rockwell Automation Support</a>	<a href="#">3</a>
<a href="#">Product Satisfaction Return</a>	<a href="#">3</a>

## Determining Firmware Revision Level

To determine the firmware version for a PowerFlex 700L Active Converter, view parameter 204 - [Control SW Ver]. The firmware version is the data in this parameter.

Example:

Firmware Version 3.001

Firmware revision from parameter 204 - [Control SW Ver] 3.001

## Firmware Upgrades

This section describes procedures to flash upgrade your firmware using HyperTerminal. Downloads are provided on the Allen-Bradley Web Updates site located at <http://www.ab.com/support/abdrives/webupdate>.

1. Remove/disconnect any HIMs before proceeding.
2. Download the flash update file from the Allen-Bradley Web Updates site.
3. Connect to the PowerFlex 700L drive using a 1203-USB or 1203-SSS Series B serial converter and HyperTerminal.
4. Select Flash Upgrade.
5. When operating as a Coupled unit (DPI SLAVE), select Port 6 to update the PowerFlex 700L Active Converter. When operating as a Stand Alone unit (DPI MASTER), select Port 0 to update the active converter.

6. Select Y to proceed.
7. Select the appropriate .bin file for the Active Converter firmware. Select X-modem for the Protocol.
8. Select send. HyperTerminal should show progress of the flash upgrade and indicate when the flash is complete.
9. You may need to cycle power after flashing is complete to re-establish communication.

## **Enhancements**

This section describes the enhancements provided in this revision of firmware:

In previous versions, the Active Converter would always limit its rated current to be less than or equal to the rated current of the associated Inverter. This change allows the Active Converter's current rating to be independent of the Inverter's current rating. This change was made to support the PowerFlex 700L Frame 2 Navy drive, which has a 216 amp rated Converter and a 180 amp rated Inverter.

## **Corrected Anomalies**

There are no anomalies corrected in this revision of firmware:

## **Known Anomalies**

This firmware revision has no known anomalies.

## **Restrictions**

No restrictions apply to this revision of firmware.

## Rockwell Automation Support

Rockwell Automation provides technical information on the web to assist you in using our products. At <http://support.rockwellautomation.com>, you can find technical manuals, a knowledge base of Frequently Asked Questions (FAQs), technical and application notes, sample code and links to software service packs, and a MySupport feature that you can customize to make the best use of these tools.

Rockwell Automation also provides complimentary phone support for drives, communication adapters, and peripherals. If you experience a problem with the adapter, please review the information in its User Manual. For further help in getting your adapter operational, contact a Customer Support representative:

United States	(1) 262.512.8176 Monday – Friday, 7am – 6pm CST
Outside United States	Please contact your local Rockwell Automation representative for any technical support issues.

For an additional level of technical phone support for installation, configuration and troubleshooting, we offer TechConnect Support programs. For more information, contact your local distributor or Rockwell Automation representative, or visit <http://support.rockwellautomation.com>.

## Product Satisfaction Return

Rockwell Automation tests all products to ensure that they are fully operational when shipped from the manufacturing facility. However, if your product is not functioning and needs to be returned:

United States	Contact your distributor. You must provide a Customer Support case number (see phone number above to obtain one) to your distributor to complete the return process.
Outside United States	Please contact your local Rockwell Automation representative for return procedure.

# Allen-Bradley Drives

U.S. Allen-Bradley Drives Technical Support - Tel: (1) 262.512.8176, Fax: (1) 262.512.2222, Email: support@drives.ra.rockwell.com, Online: www.ab.com/support/abdrives

**[www.rockwellautomation.com](http://www.rockwellautomation.com)**

---

**Power, Control and Information Solutions Headquarters**

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846