



ATTENTION: WHEN NOT USING AN ISOLATION CONTACTOR, HAZARDOUS VOLTAGES ARE PRESENT AT THE LOAD TERMINALS OF THE CONTROLLER EVEN WHEN THE CONTROLLER IS TURNED OFF. AT INSTALLATION, WARNING LABELS (WHICH ARE SUPPLIED) MUST BE ATTACHED TO THE MOTOR TERMINAL BOX, THE CONTROLLER ENCLOSURE AND THE CONTROL STATION. CUSTOMER MUST PROVIDE ADDITIONAL CIRCUITRY FOR AUTOMATIC ISOLATION.

(POWER FACTOR CORRECTION CAPACITORS MUST NOT BE CONNECTED AT LOAD SIDE OF SMC-2)

NOTE: FACTORY SETTINGS MAY NOT BE SUITABLE FOR YOUR APPLICATION. REFER TO SMC INSTALLATION MANUAL.

SMC-2™ CONTROL TERMINALS

CONTROL DEVICE WIRING



THE CIRCUIT IS TYPICAL OF A 5 AMP BUL 2154E SMC UNIT WITH TRANSFORMER CONTROL

OPTIONS:
- A 480/120V CONTROL TRANSFORMER WITH PRIMARY FUSES

NOTES

- [1] REMOTE DEVICE
- [2] BULLETIN 150 SOLID STATE MOTOR CONTROLLER. REFER TO SMC USER MANUAL FOR APPLICATION DATA.

A COMPLETE AND ACCURATE REPRESENTATION OF THE CIRCUIT DEPENDS ON THE SIZE AND OPTIONS ORDERED.

References		BUL. 2154E 5 AMP		
Revision	Release	Dimensions Apply Before Surface Treatment	Dimensions in Inches Tolerances Unless Otherwise Specified	
1	08/20/01	2 Place Decimal ±.02	3 Place Decimal ±.005	Dr. _____ Date _____
Refer. Book		Angles ±1		Chkd. _____ Date _____
				Appd. _____ Date _____

Sheet 1 Of 1
Dwg Size C
2154EWB001