



## Remove Jumpers in Kinetix 7000 Drives

Catalog Numbers 2099-BM06-S, 2099-BM07-S, 2099-BM08-S, 2099-BM09-S, 2099-BM10-S, 2099-BM11-S

This product note provides information regarding the protective MOVs and common mode capacitors included with the Kinetix 7000 drives.

---

**ATTENTION**

Kinetix 7000 drives contain protective MOVs and common mode capacitors that are referenced to ground. In a grounded power distribution system, these devices assist in isolating the drive from electromagnetic interference (EMI).

These devices must be disconnected if the drive is installed in:

- unbalanced, ungrounded, or resistive-grounded power distribution systems.
- common bus configurations.

---

The MOVs, capacitors, and a sticker describing this issue, are located within the power terminal block. Refer to the Kinetix 7000 High Power Servo Drives Quick Start, publication 2099-QS001, for more information.

Kinetix is a trademark of Rockwell Automation, Inc.  
Trademarks not belonging to Rockwell Automation are property of their respective companies.

[www.rockwellautomation.com](http://www.rockwellautomation.com)

---

### Power, Control and Information Solutions Headquarters

Americas: Rockwell Automation, 1201 South Second Street, Milwaukee, WI 53204-2496 USA, Tel: (1) 414.382.2000, Fax: (1) 414.382.4444

Europe/Middle East/Africa: Rockwell Automation, Vorstlaan/Boulevard du Souverain 36, 1170 Brussels, Belgium, Tel: (32) 2 663 0600, Fax: (32) 2 663 0640

Asia Pacific: Rockwell Automation, Level 14, Core F, Cyberport 3, 100 Cyberport Road, Hong Kong, Tel: (852) 2887 4788, Fax: (852) 2508 1846

Publication 2099-PA001A-EN-P — May 2006

PN 328028-P01

Copyright © 2006 Rockwell Automation, Inc. All rights reserved. Printed in the U.S.A.